


# *Thermal Wave® 5M*



## Service and Operation Manual

**BLUELINE Equipment Co. LLC**

2604 Liberator Dr., Prescott, AZ 86301 1-928-445-3030

**Congratulations** on your purchase of the **THERMALWAVE® 5M** truck mount cleaning unit. This instruction/parts manual is a guide for operating and servicing your **BLUELINE** unit.

Proper operation and service are necessary to ensure the outstanding performance of this unit. When properly maintained, your truck mount will have a long and trouble-free life.

The following service methods outlined in this manual are detailed in a manner that operation and servicing may be performed properly and safely. Because service levels vary due to the skill of the mechanic, tools and parts availability, ensure that prior to attempting any repair, you are familiar with this equipment and have the proper tools. Any questions regarding the operation, service, or repair of this unit should be directed to your nearest **BLUELINE** dealer.

The headings **WARNING** and **CAUTION** are utilized to warn you that steps must be taken to prevent personal injury or damage to the equipment. Please make sure that you have read and understand these instructions entirely before proceeding with the operation of this unit.

**THIS UNIT MUST BE INSTALLED BY THE DEALER THAT YOU PURCHASED IT FROM IN ACCORDANCE WITH THE BLUELINE INSTALLATION PROCEDURES.**

**PLEASE ENSURE THAT THE WARRANTY CARD IS FILLED OUT BY THE DISTRIBUTOR THAT YOU PURCHASED THIS UNIT FROM AND RETURNED TO BLUELINE.**

Record your units serial number here for future reference or if you should need to contact the factory in the future for any reason.

S/N:

This service and operations manual is written specifically for **BLUELINE THERMALWAVE® 5M** Truck Mount Cleaning units manufactured by:

**BLUELINE EQUIPMENT LLC**

2265 Crosswind Drive  
2604 Liberator  
Prescott, AZ 86301 USA

The information contained in this document is subject to change without notice and does not represent a commitment on the part of **BLUELINE EQUIPMENT LLC**.

All rights reserved. Copyright 2002 by **BLUELINE EQUIPMENT LLC**. No part of this work may be used or reproduced in any form or means without the express written consent and permission of **BLUELINE EQUIPMENT LLC**.

Published by **BLUELINE EQUIPMENT LLC**.  
First printing: October 2002  
Printed in USA

**THERMALWAVE® 5M MANUAL  
PART# 49-002**

June 05

# **LIMITED WARRANTY**

**BLUELINE** warrants your machine to be free of defects in material and workmanship. This warranty shall extend to the designated parts for the specific period of time listed from the date of delivery to the user. If **BLUELINE** receives notice of any defects during the warranty period, **BLUELINE** will either, at its option, repair or replace products that prove to be defective. Any transportation, related service labor, normal maintenance and diagnostic calls are not included.

Gasoline Engine (Through manufacturer or local dealer)	_____	1 year
Vacuum Pump (Through manufacturer or local dealer)	_____	18 months
Water Pump	_____	1 year
Waste Pump	_____	1 year
Engine Heat Exchanger	_____	1 year
Wands (Excluding shut off valve and orifices)	_____	1 year
Waste and Water Tanks	_____	1 year
Pressure Regulator	_____	1 year
Battery (pro-rated)	_____	1 year
All Other Components	_____	1 year

This warranty shall not apply to defects caused by improper installation or operation, inadequate maintenance by the customer, unauthorized modification or misuse, improper repair, freezing or damage due to hard water scaling.

Electrical components, disposable filters, belts, hoses, fittings, o-rings and other service maintenance items are not under warranty. Components supplied by **BLUELINE**, but provided by other manufacturers, will only be warranted to the extent that they are warranted to **BLUELINE**.

To receive warranty service, products must be returned to a **BLUELINE** designated service facility. The customer shall prepay shipping charges for products returned to **BLUELINE** for warranty evaluation and **BLUELINE** shall pay for the return of products to the customer.

**BLUELINE** makes no other warranty, expressed or implied, with respect to this product. **BLUELINE** disclaims the implied warranties of merchantability and fitness for a particular purpose. Any implied warranty of merchantability or fitness is limited to the specific duration of this limited warranty.

This warranty gives the customer specific legal rights, and you may also have other rights that may vary from state to state, or province to province.

The remedies provided herein are the customer's sole and exclusive remedies. In no event shall **BLUELINE** be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

# Table of Contents

## SECTION ONE: GENERAL INFORMATION

- |   |          |
|---|----------|
| <b>1. SAFETY</b> _____  | <b>2</b> |
| <i>Safety, Specifications, Installation, Fuel, Engine Oil, Chemical, Water Requirements</i> |          |
| <b>2. RECEIVING YOUR TRUCK MOUNT UNIT</b> _____   | <b>7</b> |
| <i>Dealer Responsibility, Acceptance of Shipment, Equipment Listing, Optional Equipment</i> |          |

## SECTION TWO: INSTALLATION

- |  |          |
|--|----------|
| <b>3. INSTALLATION</b> _____   | <b>8</b> |
| <i>Lifting the Unit into the Vehicle, Positioning the Unit into the Vehicle, Fastening Down the Unit and Waste Tank, Dimensional Diagrams, Installation of Fuel Lines, Trailer Fuel Tank and Fuel Line Installation, Battery Connection, Fire Extinguisher, Console to Waste Tank Connection</i> |          |

## SECTION THREE: OPERATION

- |   |           |
|---|-----------|
| <b>4. SYSTEMS</b> _____   | <b>15</b> |
| <i>Water Pumping System, Heat Transfer System, Vacuum System, Chemical System</i>   |           |
| <b>5. OPERATION</b> _____   | <b>19</b> |
| <i>Equipment setup, Instrumentation, Starting Your Unit, Priming the Chemical Pump, Waste Pump, Operation, Cleaning, Upholstery Cleaning, Stair Tool Cleaning, Flood Restoration, Shut Down and Daily Maintenance, Freeze Protection.</i> |           |

## SECTION FOUR: MAINTENANCE and SERVICE

- |   |           |
|---|-----------|
| <b>MAINTENANCE CHART</b> _____              | <b>29</b> |
| <b>6. MAINTENANCE</b> _____                 | <b>30</b> |
| <b>7. GENERAL SERVICE ADJUSTMENTS</b> _____ | <b>34</b> |
| <b>8. TROUBLESHOOTING</b> _____             | <b>39</b> |

## SECTION FIVE: PARTS and ACCESSORIES

- |  |           |
|--|-----------|
| <b>9. ILLUSTRATED PARTS LISTINGS</b> _____ | <b>49</b> |
| <b>10. ACCESSORIES</b> _____               | <b>84</b> |



# **SECTION 1:** **GENERAL INFORMATION**

## **1. SAFETY**

Safety	2
Specifications	5
Installation requirements	6
Fuel requirements	6
Engine oil requirements	6
Chemical requirements	6
Water requirements	6



## **2. RECEIVING YOUR TRUCK MOUNT UNIT**

Dealer responsibility	7
Acceptance of shipment	7
Equipment listing	7
Optional equipment	7

# 1. SAFETY

## **WARNING For Your Safety!**

The following **WARNING** labels are on your THERMALWAVE® console. These labels point out important **Warnings and Cautions**, which must be followed at **all** times. Failure to follow warnings could result in personal injury, fatality, to yourself and/or others or property damage. Please follow these instructions carefully! **DO NOT** remove these decals.



 **WARNING!**

**1. Read the operator's manual before starting this unit.**

Failure to adhere to instructions could result in severe personal injury or could be fatal.

**2. Operate this unit and equipment only in a well-ventilated area.**

Exhaust fumes contain carbon monoxide, which is an odorless and deadly poison that can cause severe injury or death. **DO NOT** run this unit in an enclosed area. **DO NOT** operate this unit where the exhaust may enter a building doorway, window, vent or other opening.

**3. Gasoline is extremely flammable and its vapors can explode if ignited.**

Store gasoline only in approved containers, in well-ventilated, unoccupied buildings and away from sparks or flames. Never carry gasoline or any flammable materials in the vehicle. Fumes could accumulate inside of the vehicle and ignite, causing an explosion.

4. This unit must be operated with the vehicle doors open in order to ensure adequate ventilation to the engine.

5. **DO NOT** operate unit if gasoline is spilled. Do not turn ignition switch until the gasoline has been cleaned up. Never use gasoline for cleaning purposes.

6. **DO NOT** place hands, feet, hair, clothing or any body parts near rotating or moving parts. Rotating machinery can cause severe injury or death.

7. **NEVER** operate this unit without belt and safety guards. High speed moving parts, such as belts and pulleys, should be avoided while the unit is running. Severe injury, fatality or damage may result.

8. **NEVER** service this unit while it is running. High speed mechanical parts as well as high temperature components may result in injury or severed limbs.

9. Engine components will be extremely hot from operation. To prevent severe burns, **DO NOT** touch these areas while the unit is running or shortly after the unit is shut off.

10. **DO NOT** touch the exhaust diverter valve or any part of the exhaust system while the system is running or for 20 minutes after the unit is shut off. Severe burns could result.

11. **Water under high pressure at high temperature can cause burns, severe personal injury, or fatality.** Shut down unit, allow to cool down and relieve system of all pressure before removing caps, valves, plugs, fittings, filters or hardware.

12. **NEVER** leave the vehicle engine running while the unit is in operation.

13. **Battery acid contains sulfuric acid.** To prevent acid burns, avoid contact with skin, eyes and clothing. Batteries also produce explosive hydrogen gases while charging. To prevent fire or explosion, charge batteries only in a well ventilated area. Keep sparks, open flames, as well as other sources of ignition away from battery at all times. Remove all jewelry prior to servicing batteries. Keep batteries out of the reach of children.

**Before disconnecting** the negative (-) ground cable, ensure that all switches are in the off position. If on, a spark could occur at the ground connection terminal which could cause an explosion if hydrogen gas or gasoline vapors are present. **ALWAYS** disconnect the negative (-) terminal first.

14. **DO NOT** smoke around the machine. Gas fumes could accumulate and ignite. Battery

## SECTION 1

gases are extremely flammable. This will prevent possible explosions.

15. **DO NOT** damage the vehicle in any way during the installation. When routing fuel lines **DO NOT** configure the hose in any locations where the hose or vehicle could be damaged. Avoid contact with moving parts, areas of high temperature, brake lines, fuel lines, catalytic converters, exhaust pipes, mufflers or sharp objects.

16. **NEVER** cut or splice any of the vehicle fuel lines during fuel line installation. This will result in fuel leaks and potentially dangerous conditions. Use only the provided fuel hose for fuel lines. When going through the vehicle floor with fuel lines, always utilize bulkhead adaptors. This will prevent fuel leaks and ensure that hoses are not punctured by vehicle vibration abrasion.

17. **DO NOT** exceed your vehicles weight limit. The console with waste tank and accessories weighs approximately 1420 pounds. Make certain that the vehicle has the correct axle rating. This will prevent unsafe or hazardous driving conditions.

18. High back seats are required for all vehicles that units are to be installed for head and neck protection. Metal partitions between the seats and equipment are strongly recommended.

19. **DO NOT** operate this unit without the water supply on and attached. The water pump and other vital components could be seriously damaged if the unit is operated dry. This unit is equipped with a low pressure shut down switch, which should **NOT** be bypassed.

20. Always keep your vehicle clean and orderly. Wands, tools and accessories must be securely stowed while driving the vehicle.

21. All high-pressure hoses must be rated at 3000 PSI and have a heat rating of 250 degrees F. Thermoplastic hoses do not meet this criteria and should never be used. Severe burns and other injuries could result if hoses do not meet these requirements.

22. Ensure that you have received proper training from the distributor that you purchased the unit from prior to operation.

23. This unit produces high pressure and high temperatures. Improper use could result in serious injury.

24. **DO NOT** modify this unit in any manner. Any modification could result in serious injury or fatality.

25. California Proposition 65 Warning: Engine exhaust from this product contains chemicals known by the State of California to cause cancer, birth defects, or other reproductive harm.

## SPECIFICATIONS

Engine Speed	2400 rpm (High speed dual wand) 1900 rpm (Medium speed single wand) 1500 rpm (Low speed upholstery) 900 rpm (Idle)
Water Pump RPM	1550 rpm
Vacuum Pump RPM	2660 rpm @ 525 cfm
Water Flow Rate	5 GPM (maximum)
Water Pump Pressure	1200 PSI (maximum)
Vacuum Relief Valve	13 in. HG
Waste Tank Capacity	115 Gallons at shutoff
Console Weight	1060 lbs.
Console Weight (with waste tank & accessories)	1420 lbs. (2220 lbs w/full waste tank)

## TORQUE VALUES

Engine Hub	720 inch/lbs. 60 ft/lbs.
Vacuum Pump Hub	192 inch/lbs. 16 ft/lbs.

## JET SIZING

**BLUELINE** recommends that the total floor tool tip size does not exceed .06". Using larger jet sizes on your **THERMALWAVE®** unit may reduce cleaning temperatures.

**Example:** Four-jet wand uses four 95015 jets. (95 deg. Spray angle w/015 orifice)  
 $.015 \times 4 = .06$

When using two wands while cleaning with this unit, **BLUELINE** recommends that the tip size in each tool does not exceed a total of .040".

**Example:** Four-jet wand uses four 9501 jets. (95 deg. Spray angle w/01 orifice)  
 $.01 \times 4 = .04$      $.04 \times 2 \text{ tools} = .08$

Upholstery tool jet size: 80015

Stair tool jet size: 9502

## INSTALLATION REQUIREMENTS

Prior to beginning the installation, read the ENTIRE “Installation” section of this manual. Since the **THERMALWAVE®** truck mount unit weighs (with waste tank and accessories) 1420 lbs., please adhere to the following recommendations prior to installing the unit.

1. The unit should **NOT** be installed in any motor vehicle of less than 3/4 ton capacity.

### **CAUTION!**

The console and waste tank with accessories must **NOT** exceed the vehicles axle weight limit.

2. If mounting the unit in a trailer, ensure that the trailer is rated for the total weight of the **unit and trailer**. Electric or hydraulic brakes must be provided, and strict compliance with all State and Federal laws must be maintained.

3. If mounting in a trailer, the **THERMALWAVE®** console must be positioned so that it balances properly with respect to the trailer axle. Ten percent (10%) of the units total overall weight (w/o accessories or water) should be on the tongue.

4. The vehicle tires must have a load rating in excess of the combined unit and vehicle weight.

5. **BLUELINE** does not recommend using any type of flooring materials that absorb water. This condition will result in rust and corrosion of the vehicle floor.


6. Insulation under rubber mats should be removed prior to installation of the unit.

## FUEL REQUIREMENTS

Use **unleaded fuel ONLY**. **NEVER** use any gasoline additives. Use only fresh, clean unleaded gasoline intended for normal automotive use. **DO NOT** use high-octane gasoline with this unit.

## ENGINE OIL REQUIREMENTS

We recommend that you use high quality detergent oil that meets at least API (American Petroleum Institute) service class SF or SG. Select the proper viscosity based on the air temperature during the time of operation. (See table below). **NOTE:** the use of less than service class SF or SG oil or extending oil change intervals longer than recommended can cause engine damage.



## CHEMICAL REQUIREMENTS

The **BLUELINE THERMALWAVE®** truck mount unit’s unique last step chemical injection system can be used with a wide variety of water diluted chemical compounds, either acidic or alkaline, depending on the work to be performed. We recommend using only the highest quality chemistry.

## WATER REQUIREMENTS

Because hard water deposits will damage the plumbing and heat exchange systems on this unit, **BLUELINE** recommends that a high quality water softener be used in areas where the water hardness exceeds 3-1/2 grains. If a water softener is used, it must have a flow capacity of at least five (5) GPM or greater, without any hose constrictions.

The use of a water softening system will reduce maintenance and reduce down time caused by hard water scaling. It will also enhance the performance

of cleaning chemicals, which will result in greater efficiency in lower concentrations.

## **2. RECEIVING YOUR TRUCK MOUNT UNIT**

### **DEALER RESPONSIBILITY**

THE **BLUELINE** DEALER THAT YOU PURCHASED THIS TRUCK MOUNT CLEANING UNIT FROM IS RESPONSIBLE FOR THE PROPER INSTALLATION OF THIS MACHINE. THE DEALER IS ALSO RESPONSIBLE FOR THE PROPER INITIAL TRAINING OF YOUR OPERATORS AND MAINTENANCE PERSONNEL.

### **ACCEPTANCE OF SHIPMENT**

Your **THERMALWAVE®** truck mount cleaning unit was thoroughly tested, checked and inspected in its entirety prior to leaving our manufacturing facility. **When receiving your unit, please make the following acceptance check:**

1. The unit should not show any signs of damage. If there is damage, notify the common carrier immediately.
2. Carefully check your equipment and packing list. The standard **BLUELINE THERMALWAVE®** unit should arrive with the following items as well as any optional accessories:

### **EQUIPMENT LISTING**

- A. **BLUELINE THERMALWAVE®** console.
- B. Operation and Service manual
- C. Installation mounting plates and bolt down kit
- D. Hose clamps for vacuum and fuel hoses
- E. Carpet wand
- F. Waste tank with shutoff switch and filters

- G. Pre-Filter box and stainless steel strainer basket.
- H. Waste tank filters.
  - I. 150 ft. of 1/4 in. high pressure solution hose with quick connects
  - J. 150 ft. of 2 in. vacuum hose
  - K. 2 vacuum hose connectors
  - L. 50 ft. water supply hose with quick connect

### **OPTIONAL EQUIPMENT**

- A. Additional lengths of vacuum hose  
Part # 18-003
- B. Additional vacuum hose connectors  
Part # 21-003
- C. Additional high-pressure solution hoses  
Part # 18-000  
(With shutoff valve Part # 18-001)
- D. Automatic waste pump kit  
Part # 68-003
- E. Demand pump system  
Part # 68-002
- F. KIT, FUEL HOOKUP CHEVY 97 & NWR. FI  
Part # 69-003FI
- G. KIT, FUEL HOOKUP CHEVY/DODGE FI  
Part # 69-004FI
- H. KIT, FUEL HOOKUP FORD FI  
Part # 69-005 FI
- I. KIT, FUEL HOOKUP 2003 CHEVY FI  
Part #69-018FI
- J. KIT, 2004 TF ADAPTER CHEVY  
Part # 69-032
- K. KIT, 2004 TF FUEL INJ. CHEVY  
Part # 69-033
- L. ADAPTOR, 2004 FORD FUEL  
Part # 69-041
- M. ADAPTOR, 2004 FUEL INJ. FORD  
Part #69-047

# **SECTION 2:** **INSTALLATION**

## **3 INSTALLATION**

Lifting the unit into the vehicle	9
Positioning the unit into the vehicle	9
Fastening down the unit and waste tank	9
Dimensional diagrams	10
Installation of fuel lines	12
Trailer fuel tank and fuel line installation	12
Battery Connection	12
Fire extinguisher	12
Console to waste tank connection	13

### 3. INSTALLATION

#### **WARNING!!!**

This unit must be bolted to the floor of the vehicle by an authorized BLUELINE DISTRIBUTOR.

#### LIFTING THE UNIT INTO THE VEHICLE

The BLUELINE THERMALWAVE® weighs approximately 1060 lbs., a forklift is necessary to place the unit into the vehicle. Place the forks into the forklift slots from the front of the unit and make **CERTAIN** that the forks are spread to the maximum width of the unit.

#### POSITIONING THE UNIT INTO THE VEHICLE

Vehicles vary in size and openings. Owners have different preferences on where in the vehicle they want their units positioned. BLUELINE strongly recommends a side door installation for the THERMALWAVE®. We **DO NOT** recommend a rear door installation.

1. Ensure that enough space is provided to assure adequate engine ventilation as well as room for service and maintenance.
2. The complete unit with waste tank and accessories **MUST NOT** exceed the vehicle's axle weight limit.
3. **NEVER** position the console closer than 12 inches from the bottom rear of the driver and passenger seats.

### FASTENING DOWN THE UNIT AND WASTE TANK

#### **CAUTION!!!**


Prior to drilling any holes in the vehicle floor, ensure that while drilling, you will not damage the fuel tank, fuel lines, or any other vital components, which could affect the safety and or operation of the vehicle.

A. The console and waste tank mounting holes will serve as a template. Drill six (6) 13/32 in. diameter holes for the console and six (6) 13/32 in. diameter holes for the waste tank.


B. Using the provided mounting hardware kit:

1. Insert six (6) 3/8-16 x 2 ½ in. hex head cap screws with flat washers through the THERMALWAVE® console mounting holes, and six (6) 3/8-16 x 2 in. hex head cap screws with flat washers through the waste tank mounting holes.
2. Install the provided mounting plates underneath the vehicle floor.
3. Screw the provided 3/8-16 hex head lock nuts on to the mounting bolts and tighten until the console and waste tank are firmly attached to the vehicle floor.


# DIMENSIONAL DIAGRAM REAR MOUNT TANK



**DIMENSIONAL DIAGRAM BOX TRUCK TANK**



**DIMENSIONAL DIAGRAM SIDE MOUNT TANK**



## INSTALLATION OF FUEL LINES



**CAUTION!!!**

**READ THESE INSTRUCTIONS IN THEIR ENTIRETY PRIOR TO PROCEEDING.**



**WARNING!**

**The Vehicle fuel lines should NOT be spliced under ANY circumstances. Severe injury or fatality could result.**

**DO NOT** damage the vehicle in any way during the installation. When routing fuel lines **DO NOT** configure the hoses in any location where the hoses or vehicle could be damaged. Avoid contact with moving parts, areas of high temperature, brake lines, fuel lines, catalytic converters, exhaust pipes, mufflers or sharp objects.

## TRAILER FUEL TANK AND FUEL LINE INSTALLATION

The following are recommendations for trailer installations:

- A. Strict compliance with all federal and state laws must be maintained.
- B. Use only fuel tanks that are manufactured specifically for gasoline, have proper vented filling caps, and outlet connections that are the same size as the inlet and return connections on the unit.
- C. **DO NOT** install fuel tanks inside any type of enclosed trailer or vehicle.



**WARNING!**

**NEVER** carry gasoline or flammable materials in an enclosed trailer or vehicle.  
**NEVER** store any type of flammable material in an enclosed trailer or vehicle.

D. Always mount fuel tanks where they will be protected from any vehicle collision.

E. When installing fuel lines from the fuel tank to the unit, use the proper size fuel line.

## BATTERY CONNECTION



**WARNING!**

**Explosive gases, Dangerous gases! Batteries contain sulfuric acid. To prevent acid burns, avoid contact with skin, eyes and clothing. Batteries also produce explosive hydrogen gases while charging. To prevent fire or explosion, charge batteries only in a well ventilated area. Keep sparks, open flames, as well as any other sources of ignition away from batteries at all times. Remove all jewelry prior to servicing batteries. Keep batteries out of the reach of children.**

**Before disconnecting the negative (-) ground cable, ensure that all switches are in the OFF position. If ON, a spark could occur at the ground connection terminal, which could cause an explosion if hydrogen gas or gasoline vapors are present. ALWAYS disconnect the negative (-) terminal first.**


A. Attach the red positive (+) battery cable from the starter solenoid on the console to the positive (+) terminal on the battery and tighten down the nut.

B. Attach the black negative (-) battery cable from the ground on the console to the negative (-) terminal on the battery and tighten down the nut.

## FIRE EXTINGUISHER

**BLUELINE**, and many government agencies, recommend that a fire extinguisher rated for A, B, and C type fires be installed into any commercial vehicle.

# CONSOLE TO WASTE TANK CONNECTION



**\*Shown with optional waste pump out kit #68-003.**

# **SECTION 3:** **OPERATION**

## **4. SYSTEMS**

Water pumping system	15
Heat transfer system	16
Vacuum system	17
Chemical pumping system	18

## **5. OPERATION**

Preparation	19
Starting the unit	21
Priming the chemical pump	22
Automatic waste pump	22
Operation	22
Cleaning	23
Upholstery cleaning	23
Stair tool cleaning	23
Flood restoration/extraction	23
Shut down and daily maintenance	23
Freeze protection	24

## **4. SYSTEMS**

**NOTE: Read and understand this section of the manual entirely before proceeding.**

This portion of the manual divides the unit up into systems and describes how each system works. Prior to proceeding into the operations and maintenance sections of this manual it is recommended that you acquire a basic understanding of how the unit functions.

### **WATER PUMPING SYSTEM**

See figures 3-1 and 5-10. Cold water enters the console through the water inlet connection located on the lower right corner of the right lower front panel. The water then flows to the water box through a float valve, which shuts off the water when the water box is full.

Water then flows through a strainer in the water box to the water pump. The water pump is plumbed to a nitrogen charged accumulator, which helps reduce pressure pulsations.

The water pump assembly also includes a high-pressure and a low-pressure shutdown switch. These switches will shut down the unit if the water pressure exceeds 1200 PSI or drops below 50 PSI for more than 5 seconds.

Water is then pumped to the pressure regulator assembly, which provides and maintains the desired pressure setting.

Water then flows from the pressure regulator through the heli-coil heat exchanger and into the high- pressure heat exchanger, where it is super-heated by the engine exhaust.

The water then flows through the check valve manifold that contains a Y-strainer and a check valve. At this point, the chemical injection takes place.

The hot solution mixture of water and chemicals then flows through the solution outlet manifold to the cleaning tool.

This unit has an automatic diverter feature. Temperature is controlled using the thermostatic control. When the water exceeds the temperature setting, the electronic rotary solenoid valve automatically positions the diverter valve, located between the engine exhaust manifold and the hi-pressure heat exchanger, into the muffler mode. At this time hot water is bypassed into the water box to preheat the water, resulting in reduced temperature fluctuations. The temperature sensor is located in the thermostat manifold, before the solution outlet.

In addition, a temperature sensor is located on the engine exhaust heat exchanger outlet. This will shut down the engine if the water temperature exceeds 285 deg. F. If this occurs, see the “**Troubleshooting**” section of this manual to find the cause of overheating prior to restarting your unit.

## HEAT TRANSFER SYSTEM


See figures 3-1 and 5-10. Water is heated through a 2 stage heat exchange system that utilizes engine coolant and super heated engine exhaust.

Stage one utilizes hot engine coolant pumped through a shell containing copper coils. The pressurized water flows through the copper coils and collects heat from the engine coolant. The water then flows to the second heat exchange system.

The second heat exchange system is an engine exhaust vessel containing a stainless steel heating

coil. Water flows through the coil and collects heat from the engine exhaust as it leaves the engine. The engine is fuel injected, which burns virtually all of the fuel up top, resulting in extremely hot exhaust gases.

This unit is equipped with an automatic diverter valve system. This system incorporates an electronic rotary solenoid with an exhaust diverter valve. When the water temperature reaches the desired setting, the solenoid automatically positions the diverter valve into the muffler mode.




3-1

## VACUUM SYSTEM

See figures 3-2 and 5-20. The vacuum flow is initiated by the vacuum pump, or blower. An air and water mixture is drawn into the vacuum inlet on the pre-filter box. The mixture flows through a strainer basket in the pre-filter box, and then into the waste tank. The air exits the waste tank through a 100 mesh filtration system, into the vacuum pump. A vacuum pump relief valve is installed for vacuum pump protection.

The air is discharged from the vacuum pump through a spiral silencer and then through an engine exhaust silencer.

A level shut off sensor is located near the top of the waste tank and will shut down the unit before the tank is at full capacity. This protects the vacuum pump from water damage. **Note:** Waste tank level shut off will not shut the unit off due to high levels of foam. The use of a quality defoamer is recommended.




3-2

**CHEMICAL PUMPING SYSTEM**

See figures 3-3 and 5-25. The chemicals are drawn from the chemical jug through a strainer into the flow meter. The flow meter indicates the rate of chemical flow.

The chemicals then flow through the chemical metering valve to the solution outlet. This valve controls the rate of flow of chemical into the cleaning solution, which is indicated on the flow meter.

The chemicals then flow through the check valve into the stainless steel pulsation chemical pump. Then, the chemical pump injects the chemicals through the check valve to the three way selector valve located on the front panel. This valve may be used to turn the chemical flow **ON**, **OFF**, or to **PRIME** the chemical pump.



3-3


# 5. OPERATION

## PREPARATION


This section of the operator's manual explains how to prepare, start, operate, shut down and maintain your **BLUELINE THERMALWAVE®** mobile cleaning unit. The **THERMALWAVE®** unit is easy to operate. However only trained operators should proceed.



**Operate this unit and equipment only in a well ventilated area. Exhaust fumes contain carbon monoxide, which is an odorless and deadly poison that can cause severe injury or death. DO NOT run this unit in an enclosed area. DO NOT operate this unit where the exhaust may enter a building doorway, window, vent or any other opening.**







**DO NOT operate this unit without constant water flow to the console.**

The low-pressure switch will automatically shut down the unit if the water pressure in the system drops below 50 PSI, for more than 5 seconds.

The high-pressure switch will automatically shut down the unit if the water pressure in the system exceeds 1200 PSI, for more than 5 seconds.

**VACUUM HOSE**

Connect the vacuum hose(s) to the vacuum inlet connection(s) at the front of the pre-filter box. Connect the opposite end of the vacuum hose(s) to the cleaning tool(s).

**JET SIZING**

**BLUELINE** recommends that the total floor tool size does not exceed “.06”. Using larger jet sizes on your THERMALWAVE® unit may reduce cleaning temperatures.

**Example:** Four-jet wand uses four 95015 jets. (95 deg. Spray angle w/015 orifice)  
 $.015 \times 4 = .06$

When using two wands while cleaning with this unit, **BLUELINE** recommends that the tip size in each tool does not exceed a total of “.04”.

**Example:** Four jet wand uses four 9501 jets. (95 deg. Spray angle w/01 orifice)  
 $.01 \times 4 = .04$   
 Upholstery tool jet size: 80015.  
 Stair tool jet size: 9502

**STARTING THE UNIT**



This unit features a fuel injection system. This eliminates the need for an oil pressure override switch, a choke cable and many other troublesome components.

1. Set the speed selector switch to the idle position.
2. Turn the ignition switch to the right intermediate position. Hold the switch in this position for approximately 3 seconds, allowing the fuel pump to pump fuel.
3. Turn the ignition switch to the furthest right position. This will engage the starter and start the engine. The engine will run at a high rate of RPM for a short period of time, then find its proper idle setting.
4. After the engine is running at its idle setting, select the desired speed setting using the throttle control switch.
5. Turn the water pump switch to the **ON** position.

**NOTE:** If the unit does not build water pressure after 5 seconds, check for adequate water supply. See “Loss of Water Pump Pressure in the “**Troubleshooting** section of this manual.

Allow adequate time for the water temperature to warm up before cleaning, approximately 10-15 minutes.

## PRIMING THE CHEMICAL PUMP

**NOTE:** BLUELINE recommends that the chemical pump be primed whenever the water pump is on. This eliminates possible pressure fluctuations and water pump pulsations related with running the chemical pump dry.

1. Insert the chemical prime tube and the chemical inlet tube into the chemical jug.

**NOTE:** When inserting the chemical tube into the chemical jug, ensure that it stays fully submerged, as the chemical pump will not function if air is allowed to enter the inlet line. **DO NOT** operate the chemical pump without the inlet strainer properly installed.

2. Turn the 3-way chemical selector valve located on the control panel to the **PRIME** position. The chemical will then flow from the chemical jug through the chemical prime tube.

If the pump does not prime, then:

- A. Place the chemical prime tube into the vacuum hose and seal off the vacuum hose. The vacuum will quickly draw chemical from the chemical jug. After the flow begins, turn the chemical selector valve to **OFF** position, insert the chemical prime tube back into the jug, and turn the chemical selector valve back to the **PRIME** position and continue the procedure.
- B. Once chemical flow with no air bubbles has been achieved, turn the chemical selector valve from **PRIME** to **METER**. With the cleaning tool open, check the flow meter and adjust the chemical metering

valve until the desired rate of chemical flow is achieved.

## AUTOMATIC WASTE PUMP

1. If your unit is equipped with an optional automatic waste pump, connect one end of the 5/8 inch or larger garden hose to the pump-out connection and the other end to an acceptable waste disposal.

2. Turn the pump-out switch located on the front console control panel to the **ON** position. The waste pump will now operate automatically throughout the cleaning period.

**DO NOT** use an outlet hose that is smaller than 5/8 in. I.D.

**NEVER** use a waste pump hose as a water inlet hose.



**NEVER dispose of waste water in a storm drain, water way or on ground areas. Always dispose of waste in accordance with Local, State and Federal laws.**

## OPERATION

After you have completed the previous steps, proceed with the cleaning operation. Place the throttle control switch to the desired cleaning mode for double, single, or upholstery cleaning. A float shut-off switch is located inside of the waste tank. It will automatically shut down the unit if the tank reaches its full capacity. If this occurs, empty the waste tank before continuing.

## **AUTOMATIC DIVERTER SYSTEM**

Your **THERMALWAVE®** unit is equipped with an automatic diverter control system. When the water reaches the desired temperature setting set by the thermostat on the front control panel, the diverter solenoid will automatically position the diverter valve into the muffler position. When the water temperature drops slightly below the desired temperature, the diverter solenoid will automatically position the diverter valve into the heat exchange position. This feature eliminates the need for a water bypass system, which fills up the waste tank.

When doing flood extraction, the water pump should be in the **OFF** position. This will signal the diverter solenoid to position the diverter valve in the muffler position.

## **CLEANING**

While cleaning, observe the following guidelines:

1. Before cleaning, ensure that the wand nozzles are functioning properly.
  - A. Hold the wand approximately one foot above the surface to be cleaned and open the wand valve. A full even spray should emit from the cleaning nozzles.
  - B. If the nozzles are not showing a full even spray pattern, adjust, clean, or replace the nozzles, if required.
2. Usually, chemical solution is applied during the push stroke of the wand during cleaning, and extraction is done on the pull stroke. For heavily soiled carpets, the wand may be used in a scrubbing action, with chemical solution applied in both push and pull strokes, provided that the final stroke is a pull stroke with no chemical injection.

## **UPHOLSTERY CLEANING**

1. Upholstery tools have a lower flow rate and smaller orifices. To accommodate the desired cleaning temperature, operate the unit in the **upholstery** mode, by setting the throttle control switch on the front control panel to **upholstery**. Set the **temperature control** to the desired setting. To maintain proper cleaning temperatures, make certain that the unit has been fully heated up prior to cleaning.
2. Always clean upholstery with a pressure setting below 300 PSI, by using the pressure regulator on the unit.

## **STAIR TOOL CLEANING**

1. Set the throttle control switch on the front control panel to the **single wand** setting. Set the **temperature control** to the desired setting. To maintain proper cleaning temperatures, make certain that the unit has been fully heated up prior to cleaning.

## **FLOOD RESTORATION/EXTRACTION**

### **CAUTION!**

1. Set the throttle control switch on the front control panel to the desired setting. Make certain that the **water pump switch** is in the **OFF** position. Proceed into the extraction process.

## **SHUT DOWN AND DAILY MAINTENANCE**

1. Flush out the chemical system with fresh water to remove any chemical residue.
2. Remove as much moisture from the vacuum hoses as possible. This will prevent spillage of

wastewater in your vehicle when returning hoses.

3. Disconnect the vacuum hoses from the pre-filter box.
  4. Turn the throttle control switch to the **IDLE** position.
  5. Turn the thermostat down to 50 deg. F.
  6. Allow the unit to run for at least **2 minutes** or until the water temperature is at or below 180 deg. F. This will also remove any moisture from the vacuum pump.
- NOTE:** If shutting down for the day: Plug the vacuum inlets on the pre-filter box and set the throttle switch to **dual wand**. Spray WD-40 (or equivalent) into the **blower lubrication cup**, located on the front of the console for **5 seconds**. This will lubricate the vacuum pump. Next, return the throttle control switch to **IDLE** position, and continue step 4.
7. Turn the ignition switch to the **OFF** position.
  8. Turn the water supply faucet off. Loosen the water supply hose at the water supply to bleed off the pressure. Unhook the water supply hose and return it to the vehicle.
  9. Activate the valves on all cleaning tools. This will relieve any remaining pressure. Disconnect the cleaning tools and solution hoses and return them to the vehicle.
  10. Drain the waste tank, disposing of wastewater in a suitable and proper location.

## **WARNING!**

**NEVER dispose of wastewater in a storm drain, water way or on ground areas. Always dispose of waste in accordance with Local, State, and Federal laws.**

11. Remove the strainer basket from the pre-filter box. Clean out any debris and re-install.

**NOTE: Damage may occur to the vacuum pump.**

Replacement and maintenance of the filter(s) will prevent rust and corrosion from entering the vacuum pump.

12. Inspect the vacuum inlet filter(s) inside the waste tank **weekly**. Remove and clean the filter(s) if there is any lint or debris present.

**NOTE:** To remove the vacuum inlet filter(s), grip the plastic hexagon section of the filter(s). Gripping the filter(s) by the screen will collapse or destroy the filter(s). Replace the filter(s) after cleaning until hand tight. **NEVER operate this unit with the filter(s) removed, damaged or improperly installed.**

13. At the end of the work day, rinse out the pre-filter box and the waste tank with fresh water. A deodorizer may be added to prevent bacterial growth.

14. Clean the vehicle interior, unit, tools, hoses etc., as needed. Inspect **ALL** equipment and accessories for any damage, leaks, wear, etc.

## **FREEZE PROTECTION**

## **CAUTION!**

**If the unit is exposed to freezing weather conditions, the water inside of the unit may freeze, resulting in SERIOUS DAMAGE to**

**the unit. The following is recommended to prevent this from occurring during the cold weather season:**

1. Always park the unit in a heated building when not in use.
2. While out in operation, avoid long periods of shut down as the unit generates heat while running. Keep the unit running just prior to leaving for the next job.
3. If a heated building is not available, winterize the unit with anti-freeze.

**It is not possible to winterize units that have auxiliary water tanks. If the unit has an auxiliary water tank(s), it must be stored in a heated building.**

#### **WINTERIZING YOUR UNIT WITH ANTI-FREEZE:**

1. Shut off the water supply to the unit and disconnect the water inlet hose from the console.
2. Connect all solution hoses and tools that may have water in them, to the console.
3. Start the unit with the water pump in the **ON** position. Open a tool valve. This will result in the low-pressure switch shutting down the unit when the water box is emptied.
4. Fill the water box with two gallons of 100% glycol based anti-freeze.
5. Start the unit and set the throttle control to the **IDLE** position. Turn the water pump switch to the **ON** position. Open a tool valve until anti-freeze comes out of the tool. Repeat this procedure with **ALL** remaining tools and hoses.

6. After the tools and solution hoses have been filled with anti-freeze, disconnect and store them.

**Recover all anti-freeze that comes out of the tools and hoses and store in an approved container. ALWAYS re-use and re-cycle anti-freeze.**

7. Prime the chemical injection system with a 100% glycol based antifreeze. Insert the chemical inlet and prime tube into the anti-freeze container. Turn the chemical valve to **PRIME** until anti-freeze comes out of the prime hose. Turn the chemical valve to the **ON** (chemical) position. Ensure that the flow meter indicates flow. Ensure that all anti-freeze that comes out of the chemical hose goes into an approved container.

After **25 seconds**, turn the chemical valve to the **OFF** position.

8. Turn the temperature control to 50 deg F. Allow the unit to run for at least **3 minutes**. The unit is now winterized.

#### **REMOVING ANTI-FREEZE FROM THE UNIT:**

1. Connect the solution hoses to the unit, with a tool attached to the opposite end. Start the unit. Turn the water pump on. Open the tool valve and ensure that the anti-freeze goes into an approved container. Allow the anti-freeze to flow into the container until the low-pressure switch shuts the unit down.
2. Fill the water box with fresh water and repeat step 1.
3. Connect the water inlet hose to the unit and turn the water supply on. Connect all tools and solution hoses that were winterized to the solution outlet connections.

Open all tool valves and drain the anti-freeze into an approved container until the water runs clear and all of the anti-freeze is purged from the hoses and tools.

4. Insert the chemical prime hose into the approved container. Submerge the chemical hose into fresh water. Turn the chemical valve to the **PRIME** position until the water runs clear through the prime hose. Remove the prime hose from the container.

5. Turn the chemical valve to the **ON** (chemical) position. This will allow water to flow to the other side of the system.

After all of the anti-freeze has been removed, the unit is ready to operate.

The anti-freeze in your approved storage container will eventually become diluted with water. When the anti-freeze level drops below 70% of the total mixture, properly dispose of it and start over with fresh 100% anti-freeze.

 **WARNING!**

**DO NOT drain used anti-freeze on the ground or into storm drains. Dispose of anti-freeze only in an approved location. Observe Local, State and Federal laws when disposing of anti-freeze.**

# **SECTION 4:** **SERVICE & MAINTENANCE**

## **6. MAINTENANCE**

Maintenance Chart	29
Engine	30
Vacuum Pump	31
Water Pump	31
Vacuum Inlet Filter	32
Drive Belts, Pulleys and Hubs	32
Water Box	32
Water Pump Inlet Filter	32
Strainer Basket	32
Bypass Manifold	33
Outlet Y-Strainer, Check Valve	33
Chemical Pump, Chemical Metering System	33
Accumulator	33
Pressure Regulator, Vacuum Hoses	33
Vacuum Hoses	33
Temperature Solenoid	33
Battery	33
High Pressure Solution Hoses	34
Temperature Probe Packing	34

## **7. GENERAL SERVICE ADJUSTMENTS**

Engine	34
Vacuum Relief Valve	34
Vacuum Pump Drive Belts	35
Water Pump Drive Belt	35
Float Valve, Bypass Manifold	35
Bypass Manifold	35
Solution Outlet Check Valve, Chemical Pump	36
Packing Nut Adjustment, Chemical Metering & Selector Valves	36
Pressure Regulator	37

Adding/Draining Engine Coolant	37
Temperature Solenoid, Temperature Capillary Tube	38

## **8. TROUBLESHOOTING**

Water Pump	40
Chemical System	41
Blower / Vacuum Pump	42
Engine Will Not Start	43
Engine Does Not Crank	44
Engine Runs for 5 Seconds	45
Z.E.E.M.S.	46
Z.E.E.M.S. Trouble Codes	47
Heating System	48

## MAINTENANCE CHART

Engine	Daily	Check engine oil level.** Fill to proper level.
Engine Coolant	Daily	Check coolant level in overflow bottle. Fill to proper level.
Vacuum Pump	Daily	Spray WD-40 (or Equivalent) into the lubrication cup for 5 seconds.
Water Pump	Daily	Check water pump oil level.*** Fill to proper level.
Vacuum Inlet Filters	Daily*	Inspect filters, clean and or replace if required.
Pre-Filter Box Strainer Basket	Daily	Empty and clean stainless steel basket.
Vacuum Hoses	Daily	Rinse with fresh water.
Waste Pump-Out (Optional)	Daily*	Inspect and remove any debris or sediment.
Engine	Weekly	Check air cleaner for damaged, dirty, or loose parts.
Engine	Weekly	Inspect air intake and cooling areas. Clean if required.
Vacuum Pump	Weekly*	Check vacuum pump oil level. Fill to proper level. <b>Do not overfill.</b>
Vacuum Inlet Filters	Weekly	Remove filters and clean.
Water Box	Weekly*	Inspect and clean filter. Replace if damaged.
Bypass Manifold	Weekly	Clean and inspect strainer and orifice.
Battery	Weekly*	Check fluid level. Fill with distilled water only. <b>Do not overfill.</b>
Engine	Monthly	Inspect drive belts for wear. Replace as needed.
Water Box	Monthly	Check float valve for proper operation.
Y-Strainer	Monthly*	Clean and remove any debris.*****
High Pressure Solution Hoses	25 Hours	Inspect for wear, damage, or impending rupture. <b>Replace if damaged.</b>
Engine	100 Hours	Change engine oil and filter.
Vacuum Pump	100 Hours	Grease bearings with extreme pressure bearing grease.
Pressure Regulator	100 Hours	Lubricate o-rings. Use only o-ring lubricant part # 13-003.
Battery	100 Hours	Clean battery terminals.
Engine	200 Hours	Check spark plugs and clean if necessary.
Engine	200 Hours	Clean engine air filter.
Chemical Metering System	200 Hours	Inspect packing nut on selector and metering valve. Adjust as needed.
Temperature Solenoid	200 Hours*	Clean hard water deposits from solenoid.
Temperature Probe Packing	200 Hours*	Inspect for leaks and tighten if needed. <b>Do not over tighten</b>
Engine	500 Hours	Change engine coolant.
Engine	500 Hours	Replace in-line fuel filter.*****
Water Pump	500 Hours	Change crankcase oil.***
Pulleys and Hubs	500 Hours	Check pulley and hub set screws for proper torque.*****
Stainless Steel Accumulator	500 Hours	Check pressure. Recharge and change bladder if needed.*****
Engine	1000 Hours	Replace spark plugs.
Vacuum Pump	1000 Hours	Drain, flush, and replace oil.*****
Chemical Pump	1000 Hours	Change diaphragm and check valves. Inspect disk.
Check Valve	1000 Hours	Check Teflon seat for abnormal wear or debris. Replace as needed.
Engine	2000 Hours	Replace air filter element.

To maximize the operating life and performance, use only recommended oils, filters and greases.

\*Or as often as required.

\*\*Change engine oil and oil filter after **first 50 hours** of operation.

\*\*\*Change water pump crankcase oil after **first 50 hours** of operation

\*\*\*\*Inspect after **first week** of operation, and remove any debris present. Inspect again after **2 to 4 weeks**.

\*\*\*\*\*Check pulley and hub set screws after **first 50 hours** of operation, and again at **100 hours** of operation.

\*\*\*\*\*Or every **6 Months**. Whichever comes first.

\*\*\*\*\*Or **Yearly**. Whichever comes first.



4. Clean the engine air filter element every **200 hours**. Replace the element every **2000 hours**.

5. Check the coolant level in the radiator overflow bottle **daily**. If no coolant is present, remove the radiator cap and add coolant. Change the coolant every **500 hours** with a 70:30 coolant to water ratio.

Replace the in-line fuel filter **yearly**.

**NOTE:** Additional engine service information can be obtained from the provided Nissan A-15 Operation and Maintenance manual. If service or repair is required, contact an authorized Nissan Service Center. They will require the serial number of the engine.


## VACUUM PUMP

**NOTE:** Refer to the provided Vacuum Pump Operation and Service Manual for specific instructions.

**Lubrication:** BLUELINE recommends that you use only AEON PD Synthetic Blower Lubricant in the gear end of the vacuum pump for all operating temperatures. AEON PD is formulated specifically for positive displacement blower service to provide maximum blower protection at any temperature. One filling of AEON PD will last a minimum of twice as long as a premium mineral oil.

**NOTE:** AEON PD (Part # 13-004) is the only oil that BLUELINE puts in the vacuum pump at the factory. Adding petroleum oil to synthetic oil is **NOT** recommended.

1. Check the oil level **weekly** to ensure the proper level is maintained. Too little oil will damage and ruin the bearings and gears. Too much oil will result in overheating.



2. A lubrication cup has been provided at the front of the console, to prevent rust from building up inside of the vacuum pump.

Run the unit for at least **2 minutes** to remove any moisture from the vacuum pump. Then, spray WD-40 (or Equivalent) into the lubrication cup for **5 seconds** while the unit is running and the vacuum inlet ports are sealed. This procedure should be done at the end of **every working day**.


3. Drain, flush and replace the oil every **1000 hours or yearly, whichever comes first**.

The bearings on the pulley end of the vacuum pump require grease lubrication every **100 hours**. Grease the bearings until grease comes out of the vent holes on the vacuum pump. Use extreme pressure bearing grease of the spec: NLGI Grade 2 EP (Part # 13-002).

## WATER PUMP

Refer to the provided Water Pump Operation Manual for specific instructions.

1. Check the crankcase oil level **daily** to ensure the proper level. If the level has dropped, check for the source of leakage and repair.



## **⚠ CAUTION!**

Ensure that when you re-torque the screws, you use a clockwise pattern and continue until the proper torque is achieved.

TORQUE VALUES		
Component	Inch/lbs	Foot/lbs
Engine Hub	720	60
Vacuum Pump Hub	192	16

2. After **50 hours** operation, change the crankcase oil with CAT Pump Crankcase Oil, (Part # 13-000). Change the crankcase oil every **500 hours** thereafter.

## **VACUUM INLET FILTERS**

1. The vacuum inlet filters in the waste tank should be inspected **daily**, and removed and cleaned **weekly**. The filter(s) will last for a long period of time if this is done.

2. Inspect the vacuum filter(s) inside the waste tank. Remove and clean filter(s) if there is any lint or debris present.

## **⚠ CAUTION!**

When removing the vacuum inlet filter(s), grip the plastic hexagon section of the filter(s). Grasping filter(s) by the screen will damage or destroy the filter(s).

## **DRIVE BELTS, PULLEYS & HUBS**

1. Check pulley set screws and hub screws after the first **50 hours** of operation and again at **100 hours**. Re-torque these screws with a torque wrench. Follow the torque values on the following table. Check pulley set screws and hub screws every **500 hours** thereafter.

2. The **THERMALWAVE®** unit features an Automatic Belt Tensioning system. This system eliminates the need for sliding the vacuum pump to achieve the proper belt tension. However, belts and pulleys should be checked periodically for wear. They should also be cleaned and inspected regularly. If wear or glazing is discovered, replacement is recommended.

## **WATER BOX**

1. The float valve should be checked at least **monthly** for proper operation. If overfilling is noted, check the plunger for proper seating. Also, check the float rod for proper adjustment.

2. The filter on the bottom of the inside of the water box is produced out of rubber with a stainless steel screen. This filter should be inspected and cleaned on a **weekly** basis, and replaced, if damaged.

**NOTE:** Prior to removing strainer, vacuum all excess water and debris from water box.

## **PRE-FILTER BOX STRAINER BASKET**

The strainer basket located in the pre-filter box should be emptied and cleaned on a **daily** basis.

## **BYPASS MANIFOLD STRAINER AND ORIFICE**

The bypass manifold strainer and orifice should be checked and cleaned of any debris **weekly**.

## **Y-STRAINER (OUTLET)**

Unscrew the screen and inspect the Y-strainer after the first **week** of operation. Remove any debris present. Inspect again after **2 and 4 weeks**. Thereafter, inspect the Y-strainer and screen at least **monthly**. If a frequent build-up of debris is noticed, inspect and clean more frequently.

## **CHECK VALVE (OUTLET)**

Inspect the check valve when servicing the chemical pump or as needed. Remove the check valve from the Y-strainer assembly and disassemble. Check the Teflon seat for abnormal wear or debris. Replace the Teflon seat if necessary. Improper seating of the check valve poppet, damaged spring, or o-rings will result in poor operation of the chemical system.

## **CHEMICAL PUMP**

The chemical pump should be rebuilt every **1000 hours**. This involves changing the diaphragm, check valves, and inspecting the disk.

## **CHEMICAL METERING SYSTEM**

Check and inspect the packing nut on the chemical selector and metering valves every **200 hours**. Keeping the valve packings properly adjusted will prevent leaks and add to the overall life of the valves.

## **STAINLESS STEEL ACCUMULATOR**

Check the dry nitrogen charge in the stainless steel accumulator at least every **6 months or 500 hours, whichever comes first**. Recharge the accumulator and replace the bladder, if necessary. This should be performed only by a **BLUELINE** Authorized Service Center.

## **WARNING!**

**Recharge the stainless steel accumulator with dry nitrogen ONLY. DO NOT charge the accumulator over 250 PSI.**

## **PRESSURE REGULATOR**

Lubricate the o-rings in the pressure regulator every **100 hours**.

Use only o-ring lubricant (Part # 13-003).

## **VACUUM HOSES**

To ensure maximum hose life, **BLUELINE** recommends that you wash out the hoses with fresh water **daily**.

## **TEMPERATURE SOLENOID**

Hard water deposits should be removed from the temperature control solenoid every **200 hours**, or as often as required.

## **BATTERY**

## **WARNING!**

**Explosive gases, Dangerous acid! Batteries contain sulfuric acid. To prevent acid burns, avoid contact with skin, eyes and clothing. Batteries also produce explosive hydrogen gases while charging. To prevent fire or explosion, charge batteries only in a well ventilated area. Keep sparks, open flames, as well as any other sources of ignition away from batteries at all times. Remove all jewelry prior**

to servicing batteries. Keep batteries out of the reach of children.

Before disconnecting the negative (-) ground cable, ensure that all switches are in the OFF position. If ON, a spark could occur at the ground connection terminal, which could cause an explosion if hydrogen gas or gasoline vapors are present. **ALWAYS disconnect the negative (-) terminal first.**

1. Check the fluid level in the battery at least **once a week**. If low, fill to the recommended level **ONLY** with distilled water. **DO NOT** overfill the battery. Early failure or poor performance will result due to loss of electrolyte.

2. Keep cables, terminals and external surfaces of the battery clean and dry. A buildup of corrosive acid or grime on the external surfaces could cause the battery to self-discharge.

3. Battery terminals should be cleaned every **100 hours** to prevent corrosion buildup. Wash the cables, terminals and external surfaces with a mild baking soda and water solution. Rinse thoroughly with fresh water. **DO NOT** allow baking soda to enter the battery cells, as this will destroy the electrolyte, resulting in battery failure.

### **HIGH PRESSURE SOLUTION HOSES**

Inspect your high-pressure solution hoses for wear after the first **100 hours**. Thereafter, inspect every **25 hours**. If the hoses show any signs of damage or impending rupture, replace the hoses.



**NEVER attempt to repair high-pressure solution hoses. Repairing high-pressure solution hoses may result in severe burns and serious injury.**

All high-pressure solution hoses must be rated for 3000 PSI at 250 deg. F. Thermoplastic hoses do not meet this requirement and should not be used. Severe burns and injury may result if the hoses do not meet these requirements.

### **TEMPERATURE PROBE PACKING**

Check the temperature probe packing for leaks every **200 hours**. Tighten the packing nut fitting just enough to stop any leaks. **DO NOT** over-tighten.

## **7. GENERAL SERVICE ADJUSTMENTS**



**DO NOT attempt to service this unit while it is running. High speed parts as well as high temperature components may result in severe injury, severed limbs, or fatality.**

### **ENGINE**

The **BLUELINE THERMALWAVE® 5M** unit features a Zenith Fuel Systems electronic fuel injection system. **DO NOT** attempt to service or repair this system without authorization from the factory.

### **VACUUM RELIEF VALVE**

With the unit running at full RPM, block off the airflow at the vacuum inlet ports and read the vacuum gauge. If adjustment is required, shut the unit down and adjust the locking nut tension on the vacuum relief valve. Re-start the unit and read the vacuum gauge. Repeat this process until the vacuum relief valve opens at 13" Hg.

## VACUUM PUMP DRIVE BELTS

The THERMALWAVE® 5M unit is equipped with an Automatic Belt Tensioning system. This eliminates the need for sliding the vacuum pump for belt adjustment. Periodic checking of the belts and pulley condition is all that is required.

## WATER PUMP DRIVE BELT

To tighten the water pump belt:

1. Loosen the four nuts, which hold the water pump base to the frame.
2. Adjust the position of the belt tensioning adjusting bolt until the proper belt tension is achieved. (3/4" deflection in the center of the belts, half way between the pulleys).
3. While checking the alignment, tighten the nuts that hold the water pump to the base.

## FLOAT VALVE (WATER BOX)

The float valve should only be adjusted if the water box is overflowing or the water level in the water box is low.

1. If the water box is overflowing, remove and check the float valve for damage, or debris. If the float ball has any water inside of it, it must be replaced.




**IF replacing the float ball, DO NOT over-tighten the float rod, as it can puncture the ball. Ensure that the nuts are tightened on the rod.**

## BYPASS MANIFOLD

The Bypass strainer and orifice should be cleaned weekly, using the following guidelines:

1. Remove the strainer, clean and re-install. **DO NOT** over-tighten.
2. Remove the cap. Remove the orifice, using a 3/16 in. Allen wrench.
3. Re-install the cap and run the unit with the water pump **ON** for at least **20 seconds** to clean out the bypass manifold.
4. Shut the unit down. Remove the cap and re-install the cleaned orifice, using a 3/16 in. Allen wrench. **DO NOT** over-tighten. Tighten orifice just enough to seat. Re-install cap. **DO NOT** over-tighten.

**NOTE:** If strainer is damaged, replace it. If o-rings leak or show wear, replace them.




Item #	Part Number	Qty.	Description
1	66-011	1	MANIFOLD, BYPASS
2	21-056	1	NIP, HEX 1/4 X 1/8 BRASS
3	21-054	3	ELL, 1-8 P X 1-4 T BRASS
4	21-079	1	TEE, PIPE STREET 1/8 BRASS
5	20-015	1	SCREEN, BYPASS MNFLD
6	41-003	2	ORING, .676ID .816OD
7	66-019	1	ORIFICE, BYPASS MNFLD. RED
8	66-017	1	CAP, CHECK VLV. BYPASS MNFOLD.

**SOLUTION OUTLET CHECK VALVE**

Inspect the check valve whenever performing service on the chemical pump or if flow problems are occurring in the chemical system.

1. Remove the check valve, ensuring that the small o-ring on the seat comes out with it
2. Next, remove the seat using a 5/16 in. Allen wrench
3. Check the Teflon seat for wear or debris. Clean and replace the seat if necessary.
4. Inspect the poppet and the spring for wear or damage. Clean and replace as necessary.
5. Re-assemble the check valve. Thread the seat by hand until snug. Then tighten with a 5/16 in Allen wrench. **DO NOT** over-tighten.



**23-023 VLV, CHECK, CHECK VLV MANIFOLD**

Item #	Part Number	Qty.	Description
1	27-009	1	CAP, CHECK VALVE ASSY. SS
2	41-007	1	ORING, 7/8 ID X 1-1/16 OD
3	15-004	1	SPRING, CHECK VALVE ASSY.
4	27-010	1	POPPET, CHECK VALVE ASSY
5	27-004	1	INSERT, SEAT-CHK VLV ASSY TM
6	27-011	1	SEAT, CHECK VALVE ASSY.
7	41-008	1	ORING, 1/2 ID 5/8 OD

**Note:** Improper seating of the check valve seat, poppet, damaged spring or o-rings will result in poor performance of the chemical system.

6. Lubricate the o-rings with o-ring lubricant. (Part # 13-003) and re-install.

**CHEMICAL PUMP**

The **THERMALWAVE®** unit features a stainless steel chemical pump and metering system. The chemical pump requires only the replacement of the diaphragm and check valves. To replace the diaphragm, unscrew the cover from the body. When replacing the diaphragm, lube the outer edges of the diaphragm with o-ring lubricant (Part #13-003) and reassemble.


To replace the check valves, remove the check valve caps, replace the check valves and reassemble using new o-rings. **DO NOT** attempt to reuse o-rings after the check valves have been removed.

**PACKING NUT ADJUSTMENT**  
**CHEMICAL**  
**METERING/SELECTOR VALVES**


Inspect the packing nut for proper tension on the chemical metering and chemical selector valves every **200 hours**. When turning the knob, there should be some resistance. If not, slightly tighten the packing nut. **DO NOT** over-tighten. Keeping the packing properly adjusted will eliminate possible leaks and will add to the overall life of the valves.

### Chemical Prime Valve

Adjust The Packing Nut By Turning The Packing Bolt Clockwise In 1/16" Increments.



### Chemical Metering Valve



## PRESSURE REGULATOR

The pressure regulator holds water pressure at a preset point and bypasses this water back to the water box.

To adjust:


1. With the unit running, close the cleaning tool valve. Check the pressure gauge. Open the tool valve. Set the pressure regulator so that the pressure gauge reads 350 PSI with the tool valve open.

With the tool valve open, there should be a normal drop of approximately 100-PSI, in pressure. **If the drop is greater than 100 PSI, it may be necessary to lubricate the pressure regulator o-rings.**

2. To adjust the pressure regulator, turn the adjusting knob (while observing the pressure gauge


on the control panel) until you reach the desired pressure.

Loosen Nut and Remove Entire Valve Stem Assembly From Valve Body To Service Seals.



Loosen This Nut To Remove Valve Stem Body.

Lubricate Both Seal & O-Ring Every 100 Hours Of Service. Use Super Lube PN# 13-003



## ADDING/DRAINING ENGINE COOLANT

Use a 70:30 coolant to water ratio in this unit's cooling system.

1. To drain the coolant, remove the upper radiator cap and turn the lower radiator draincock counter-clockwise. Open the draincock on the heli-coil assembly, until drained.

## TEMPERATURE CAPILLARY & PACKING ASSEMBLY.

### INSTALLATION:

1. Thread the tapered end of the union fitting into the thermostat manifold and tighten. Use thread sealant.
2. Slide the jam nut over the bulb of the capillary with the threaded end toward the end of the capillary bulb.
3. Insert the bulb through the union fitting and into the thermostat manifold.
4. Put the rubber seal onto the capillary tube with the split facing 90 deg. from the top. (See capillary union detail).
5. Place the four brass disks onto the capillary tube with two of the brass disks on each side of the rubber seal. Face the notch on one brass disk toward the nearest disk to lock the disks together. Next, face the notches on the disks 90 deg. from the split in the rubber seal.

Lubricating the facing sides of the brass disks will help hold them together on the capillary tube during installation.

6. Insert the rubber seal and the brass disks into the union fitting, hand tighten.

7. Place the capillary bulb into the temperature manifold as shown. When positioning the bulb, **do not** allow the bulb to compress against the support fitting.

8. Tighten the jam nut lightly, approximately 1-1/2 turns.

9. Inspect the assembly for leaks and tighten just enough to eliminate any leaks. **DO NOT** over-tighten.


2. To add coolant, fill the radiator, then bleed the air out of the system by turning the draincock on the heli-coil counter-clockwise. The heli-coil assembly is located on the right hand side of the console while facing the front of the unit. After bleeding the air out of the heli-coil draincock, close the draincock by turning it clockwise. Fill the engine radiator again. Next, fill the overflow container **ONLY** halfway between the “add” and “fill” marks. After running the unit, if necessary, add more coolant to the overflow container only.


## TEMPERATURE SOLENOID

The temperature solenoid could become seized up due to hard water and mineral deposits. Ensure that the core moves freely in the stem. The plunger must also move freely within the guide. To clean, use #0000 steel wool.

Inspect the seat to ensure that it is not distorted. Clean the seat using a 3/64 in. drill bit. **ROTATE THE DRILL BIT WITH YOUR FINGERS ONLY.**

**DO NOT** over-tighten the nut when re-assembling the temperature solenoid. Over-tightening will damage the coil.





**temperature components may result in severe injury, severed limbs or fatality.**

This section of the operator's manual describes how to look for and repair malfunctions, which may occur.

Accurate troubleshooting is based on a thorough and complete understanding of the **WATER, CHEMICAL, VACCUM, HEAT TRANSFER, SAFETY** and **WIRING** systems featured in this unit.

## **8. TROUBLESHOOTING**


**⚠ WARNING!**

**DO NOT attempt to service this unit while it is running. High-speed parts as well as high**

If there are malfunctions occurring on this unit which you do not understand, refer back to the **OPERATION** section of this manual and review **SYSTEMS**.


# Water Pump

Note: Make sure the Pump has oil, the Water Box is full of water, and the Chemical System is turned OFF. Anytime you have a Pump Pressure problem, you are actually looking for a Pump Volume problem.  
 Note: Water may be HOT and UNDER PRESSURE. EXTREME CAUTION should be used!!!




# Chemical System

Note: Use a jug with fresh water only to diagnose chemical system.  
 Note: If chemical system works with just fresh water, your problem is with your chemical and not the system.  
 Note: Make sure the water system is working before you proceed.




## Blower/Vacuum Pump

Note: Make sure the Blower has oil, the Waste Tank and Pre-Filter Box are empty and their filters are clean.  
 Note: Anytime you have a Blower Vacuum problem, you are actually looking for an Air Volume problem!




## Engine Doesn't Start

Note: Your Engine is equipped with a Zenith Fuel Injection System (Z.E.E.M.S.). Engine diagnosis is the same as an Engine with a Carburetor.  
 Note: Make sure the Engine has oil and antifreeze; Waste Tank is empty, and that you have at least a half tank of gasoline.




## Engine Does not Crank

Note: Make sure the Engine has oil; Waste Tank is empty, and you have at least a half tank of gasoline!



## Engine Runs for 5 Seconds

**Note:** Your Engine is equipped with a Zenith Fuel Injection System (Z.E.E.M.S.). Engine diagnosis is the same as an Engine with a Carburetor.  
**Note:** Make sure the Engine has oil and antifreeze; Waste Tank is empty, and that you have at least a half tank of gasoline.



# SECTION 4

## Z.E.E.M.S.


Note: Fuel may be Under Pressure Extreme Caution Should be used!!!

Have Machine Serviced by an Authorized Blue Line Service Center!

With a Multimeter Ohm (Ω) out the Wiring Harness to see if there are any Shorts or Opens. See Chart Below Does the Wiring Harness check out to be good?

### Definition of Terms

ECU	Electronic Control Unit
ECTS	Engine Coolant Temperature Sensor
IATS	Intake Air Temperature Sensor
IMAPS	Intake Manifold Absolute Pressure Sensor
ZEEMS	Zenith Electronic Engine Management System



Back side of Connector  
Black 23 Pin Connector (Engine Input)

Connector #   To Where	Wire Color
1 ECTS	Green
2 Not Used	
3 Not Used	
4 IMAPS	Orange
5 # 3 on Gray 12 Pin Connector	Yellow/Black
6 Not Used	
7 Not Used	
8 Oil Pressure Sensor	Pink
9 IATS	Dark Blue
10 Not Used	
11 IMAPS, ECTS, & IATS	Black
12 Not Used	
13 # 2 on Gray 12 Pin Connector	Red/Black
14 Not Used	
15 # 4 on Gray 12 Pin Connector	White/Black
16 Not Used	
17 IMAPS	Light Green
18 Not Used	
19 Not Used	
20 Not Used	
21 Not Used	
22 Not Used	
23 Not Used	


Back side of Connector  
White 23 Pin Connector (Engine Output)

Connector #   To Where	Wire Color
1 Not Used	
2 Not Used	
3 Gasoline Injector	Brown
4 # 5 on Gray 12 Pin Connector	Purple
5 Governor Actuator Connector	Gray
6 Not Used	
7 # 6 on Gray 12 Pin Connector	White/Green
8 Not Used	
9 # 9 on Gray 12 Pin Connector	Orange
10 Not Used	
11 Not Used	
12 # 10 on Gray 12 Pin Connector	Red/White
13 Not Used	
14 # 11 on Gray 12 Pin Connector	Dark Blue
15 Gasoline Injector	Red/Black
16 # 7 on Gray 12 Pin Connector	White
17 Not Used	
18 Not Used	
19 Ignition Coil (-) Lead	Light Blue
20 Ground & Governor Actuator Connector	Black
21 Ground & Governor Actuator Connector	Black
22 Ignition Coil (+) Lead, Alt Sense Wire, & # 1 on Gray 12 Pin Connector	Red
23 Ignition Coil (+) Lead, Alt Sense Wire, & # 1 on Gray 12 Pin Connector	Red

Z.E.E.M.S. Side | Machine Side

Back side of Connector  
Gray 12 Pin Connector

Connector #   What	Wire Color
1 Power to ECU	Red
2 Speed # 1	Red/Black
3 Speed # 2	Yellow/Black
4 Speed # 3	White/Black
5 Fuel Pump	Purple
6 Low Level Driver	White/Green
7 Aux Input Ground	White
8 Starter Solenoid	Green/Black
9 Aux Input 12 Volts	Orange
10 Check Engine Light	Red/White
11 Low Level Lamp Driver	Dark Blue
12 Battery	Red



**SECTION 4**

**Z.E.E.M.S. EMISSION CODES**


CONDITION	RESULT	TROUBLE CODE	TROUBLE FLAG	CODE/FLAG RETAINED INMEMORY WITH KEY OFF?	EMISSION CONTROL INDICATOR LIGHT
ENGINE OIL PRESSURE SWITCH INDICATES LOW OIL PRESSURE	OIL PRESSURE SWITCH INDICATES OIL PRESSURE IS LOW FOR 1 COMPLETE SECOND - ENGINE SHUTDOWN OCCURS (AFTER 5 SECOND BYPASS DELAY UPON STARTUP)		2	NO	FLASHES CONTINUOUSLY - ALERTS OPERATOR ENGINE SHUTDOWN HAS OCCURRED
ENGINE OVERHEATING DETECTED	COOLANT TEMPERATURE INDICATES OVER HEATING CONDITION (AFTER 40 SECOND HOT SOAK TIME DELAY UPON STARTUP)		3	NO	FLASHES CONTINUOUSLY - ALERTS OPERATOR ENGINE SHUTDOWN HAS OCCURRED
BEGINNING OF DIAGNOSTIC ROUTINE	NO FAULT CONDITION EXISTS - SIGNIFIES BEGINNING OF FLASH CODES	12		YES-ALWAYS PRESENT	ALWAYS FLASHES CODE 12 AT THE BEGINNING OF DIAGNOSTIC CYCLE- SIGNIFIES CIRCUIT IS OPERATIONAL
ENGINE COOLANT SENSOR INDICATES SHORT CIRCUIT OR EXTREME OVERHEATING OF ENGINE (COOLANT TEMP >= 266 F)	TROUBLE CODE IS STORED IN MEMORY	14	3	CODE RETAINED IN MEMORY	UPON INITIAL FAULT-EMISSION CONTROL LIGHT WILL FLASH CONTINUOUSLY ALERTING OPERATOR ENGINE SHUTDOWN HAS OCCURED - UPON RESTART, "EMISSION CONTROL" LAMP IS ON CONTINUOUS INDICATING CODE WAS STORED
ENGINE COOLANT SENSOR INDICATES OPEN CIRCUIT	TROUBLE CODE IS STORED IN MEMORY	15		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
AIR TEMPERATURE SENSOR INDICATES OPEN CIRCUIT	TROUBLE CODE IS STORED IN MEMORY	23		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
AIR TEMPERATURE SENSOR INDICATES SHORT CIRCUIT	TROUBLE CODE IS STORED IN MEMORY	24		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
MAP SENSOR CIRCUIT INDICATES HIGH VLOTAGE (4.98 V OR ABOVE)	TROUBLE CODE IS STORED IN MEMORY	33		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
MAP SENSOR CIRCUIT INDICATES SHORT TO GROUND	TROUBLE CODE IS STORED IN MEMORY	34		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
OXYGEN SENSOR - LEAN CONDITION DETECTED	TROUBLE CODE IS STORED IN MEMORY	44		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED
OXYGEN SENSOR - RICH CONDITION DETECTED	TROUBLE CODE IS STORED IN MEMORY	45		CODE RETAINED IN MEMORY	ON CONTINUOUS WHILE ENGINE IS RUNNING INDICATING CODE WAS STORED

# SECTION 4

## Heating System

Note: Make sure the Engine and Water Pump System are working Properly.  
 Note: Water may be Hot and Under Pressure Extreme Caution Should be used!!!

With the Ignition Key in the Off Position. Slowly turn the Thermostat up and down. You will hear the Thermostat Microswitch Click at Approximately the Temperature that the water in the machine is. Do you hear the Thermostat Microswitch Click at Approximately the Temperature that the water in the machine is?



# **SECTION 5:** **SERVICE & MAINTENANCE**


## **9. ILLUSTRATED PARTS LISTINGS**

Sheet Metal	50
Engine	54
Water Transfer System	59
Vacuum-Exhaust System	69
Chemical Pumping System	74
Decals	76
Electrical Diagram	77
Optional Equipment	78

## **10. ACCESSORIES**

Accessories	84
-------------	----


SECTION 5



5-1  
**SHEET METAL FRAME**

Item No.	Part Number	Qty	Description
1	61-107	1	ASSY,BASE TM5 CATALYTIC
2	61-017	1	ASSY, UPR CONTROL PANEL MT
3	61-009	1	MT, ASSY REAR ENGINE THERMAL WAVE
4	59-010	1	PNL, EXTENSION REAR MTR PLATE
5	61-013	1	PNL, FIN RGT BELT GUARD THERMAL
6	58-008	1	PNL, BELT GUARD LEFT THERM
7	58-005	1	BRKT, MTG. WTR BOX HLD DWN LFT
8	59-008	1	BRKT, MTG WTR BOX HLD DWN RT
9	10-028	4	SCREW, MACH 1/4-20 X 2-3/4 HXHD
10	10-032	12	SCREW, MACH 1/4-20 X 3/4 HXHD
11	12-012	15	WASHER, FLAT 1/4 SAE
12	10-030	6	SCREW, MACH 3/8-16 X 3 HXHD
13	12-013	12	WASHER, FLAT 3/8 SAE
14	12-014	6	LKWSR, 3/8 ZINC
15	11-006	6	NUT, 3/8-16 ZINC
16	12-015	13	LKWSR, 1/4 ZINC
17	10-026	1	SCREW, MACH 1/4-20 X 1 HXHD
18	11-004	4	NUT, 1/4-20 ZINC
19	61-036	1	ASSY, GREASE TRAP THERM
20	14-005	2	CLAMP, WIRE 1/2 IN X 1/4
21	58-033	1	BRKT, COWL SILENCER SUPPORT

SECTION 5




5-2

**FRONT SHEET METAL**

Item No.	Part Number	Qty	Description
1	58-000	1	RING, RETAINER GRILL THERMAL WAVE
2	61-010	1	PNL, FIN. FRT. GRILL CVR. THERMAL
3	69-013	1	ASSY, CONTROL PANEL THERMAL
4	58-099	1	PNL, LWR LEFT FRONT THERM
5	58-100	1	PNL, LOWER LEFT THERMAL
6	61-015	1	PNL, FIN LWR RT FRT THERMAL
7	10-007	39	SCREW, MACH 1/4-20 X 1/2 SOCHD SS
8	12-011	41	WASHER, FLAT #12 SAE
9	10-016	9	SCREW, MACHINE 10-32 X 1 SOCHD SS
10	11-002	9	NUT, WELL G 10-32 .375
11	61-134	1	ASSY, BRACKET WATER INLET
12	10-009	2	SCREW, CARRIAGE 1/4-20 X 3-1/2
13	12-015	2	LKWSR, 1/4 ZINC
14	11-004	2	NUT, 1/4-20 ZINC
15	41-031	1	GROMMET, 1-1/2ID X 2-1/8OD
16	41-020	1	GROMMET, 1-7/8 OD X 1-1/4 ID

SECTION 5




5-3

**69-013 CONTROL PANEL THERMAL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	58-002	1	PNL, CONTROL THERMAL WAVE
2	29-011	1	SWITCH, THROTTLE CONTROL
3	30-022	1	LIGHT,LED AMBER
4	29-007	1	SWITCH,STARTER&KEY3POSITION
5	31-011	2	PANEL, MTG. END # 44383 WAYTEK
6	31-012	2	PANEL, MTG. MIDDLE # 44384 WAYTEK
7	29-012	4	SWITCH, PUMP AND AUX. DSCVRY
8	30-007	1	BREAKER, 30 AMP
9	30-008	4	BREAKER, 20 AMP
10	34-007	1	CONTROL, TEMP 275 DEGREE
11	26-010	1	HOURLMETER, HOBBS
12	26-007	1	GAUGE,WTR. TEMP 320 DEG
13	26-005	1	GAUGE, WTR. PRESS1500PSIDUAL
14	26-004	1	GUAGE, VAC 30in.HG DUALSCALE
15	23-027	1	VLV, 3-WAY BALL 1/8 FP SS
16	26-003	1	FLOWMETER, 1/8P
17	23-028	1	VLV, MET 1/8FP (CHEM) RT ANG SS
18	34-010	3	RELAY, ENG.SHUTDWN12V20/30AMP
19	58-114	1	BRKT, RELAY MOUNT THERM
20	16-026	36"	HOSE, WINDSHIELD WIPER 50 FT BULK
21	21-037	1	ELL, 1/4 IN. BRASS
22	21-076	1	BUSHING, 1/4 M X 1/8 F BRASS
23	21-028	1	CONN, 1/8 P X 1/4 POLY
24	21-004	1	CONN, 1/4 F P X 1/4 T BRASS
25	21-007	3	FTTG,BRB 1/8 PX 5/16 H BR
26	21-054	2	ELL, 1-8 P X 1-4 T BRASS
27	21-001	2	CONN, 1/8 P X 1/4 T BR
28	21-038	1	ELL, STREET 1/8 IN. BRASS
29	10-033	2	SCREW, MACH 10-32 X 3/8 PHILLIP


SECTION 5



5-4  
HOOD ASSY

Item No.	Part Number	Qty	Description
1	61-019	1	ASSY, FIN HOOD SCOOP THERMAL WAVE
2	58-011	1	HOOD, RIGHT THERMAL WAVE
3	58-012	1	HOOD, LEFT THERMAL WAVE
4	11-007	6	NUT, THUMB 1/4-20 FKWR HEAD KNOB
5	11-009	6	NUT 1/4-20 NYLON
6	10-021	5	SCREW, MACH 1/4-20 x 3/4 SOCHD SS
7	12-002	10	FLATWASHER, 1/4 SS ANC
8	12-003	5	LOCKWASHER, 1/4 SS
9	11-001	5	NUT, 1/4-20 SS


## SECTION 5



5-5

### ENGINE INSTALLATION

Item No.	Part Number	Qty	Description
1	45-007	1	ENGINE, NISSAN A-15 BLUELINE SPC
2	36-145	1	MODULE, EFI ZEEMSW/CLOSED LOOP
3	37-016	1	BELT, ALT. NISSAN#11720-77702
4	37-010	1	BELT, AX45 MATCH
5	61-006	1	MT. CTR ENGINE RIGHT A-15
6	61-007	1	MT. CTR ENGINE LEFT A-15
7	10-057	2	BOLT, TAP 3/8-16 X 3 GR 5
8	12-017	8	WASHER, FLAT 5/16 SAE
9	12-014	4	LKWSR, 3/8 ZINC
10	10-029	2	SCREW, MACH 3/8-16 X 1 HXHD
11	11-006	4	NUT, 3/8-16 ZINC
12	11-010	4	NUT, M8 HARD
13	12-005	4	LKWSR, M8 HARD
14	21-016	1	ELL, #6BSTX 1/2 T ZNC PL
15	18-005	1	HOSE, HP 3/8 X 13 IN. OIL DRAIN NIS
16	35-004	1	BATTERY, 12 VOLT LAWN & GARDEN
17	40-004	1	BOX, BATTERY HOLDER
18	47-002	1	ASSY, BATTERY CABLE BLK THERMAL
19	47-001	1	ASSY, BATTERY CABLE RED THERMAL
20	10-032	2	SCREW, MACH 1/4-20 X 3/4 HXHD
21	11-004	2	NUT, 1/4-20 ZINC
22	21-027	1	PLUG, 1/2 T BRASS
23	29-013	1	SWITCH, OIL PRESSURE HOBBS CLOSED
24	21-099	1	ELL, 1/8 45 DEG BRASS
25	21-038	1	ELL, STREET 1/8 IN. BRASS
26	36-009	1	FILTER, OIL NISSAN A-15




5-6

### RADIATOR INSTALLATION

Item No.	Part Number	Qty	Description
1	63-000	1	RADIATOR, RS-4849 NISSAN A-15
2	41-013	2	GROMMET, RAD MTG. BTM
3	41-015	2	WASHER, RAD MTG.
4	41-016	1	GROMMET, RAD MTG. SIDE
5	12-016	3	LKWSR, 5/16 ZINC
6	10-034	1	SCREW, MACH 5/16-18 X 3/4 HXHD
7	11-005	2	NUT, 5/16-18 ZINC
8	10-019	2	SCREW, MACH 1/4-20 X 3/4 FLTHD
9	12-012	1	WASHER, FLAT 1/4 SAE
10	36-140	1	BOTTLE, O FLOW 2 LITER
11	58-091	1	PNL, FAN SHROUD A-15

## SECTION 5




5-7

### ENGINE FUEL SYSTEM

Item No.	Part Number	Qty	Description
1	36-076	1	MODULE, ZEEMS EFI #0-20022
2	36-117	1	HOSE, PCV THERMAL #249908
3	16-029	11"	HOSE, FUEL 3/8 IN 30R7
4	16-029	40"	HOSE, FUEL 3/8 IN 30R7
5	16-029	33"	HOSE, FUEL 3/8 IN 30R7
6	36-125	1	PUMP, FUEL W/RETURN ZENITH
7	10-035	3	SCREW, 1/4 X 1 HXHD
8	14-007	8	CLAMP, HOSE # 4
9	14-012	7	CLAMP, HOSE #8
10	21-006	1	FTTG, BRB 1/4P X 5/16 H BR
11	21-060	1	ELL, STREET 1/4 45DEG BRASS
12	21-123	1	FTTG, BRB 1/4 PX 3/8 H BR
13	61-018	1	BRKT, FIN FUEL RETURN THERMAL
14	21-007	2	FTTG, BRB 1/8 PX 5/16 H BR
15	21-038	1	ELL, STREET 1/8 IN. BRASS

## SECTION 5




5-8

### ENGINE COOLING SYSTEM

Item No.	Part Number	Qty	Description
1	66-024	1	MANIFOLD, ENG THERMOSTAT BYPASS
2	66-033	1	3/4 NPT TO 1-1/8 HOSE
3	36-134	1	THERMOSTAT, NISSAN A-15 205 DEG
4	36-109	2	GASKET, THERMOSTAT A-15
5	10-036	2	SCREW, MACH 5/16-18 X 1-1/4 HXHD
6	12-016	2	LKWSR, 5/16 ZINC
7	16-008	13.5"	HOSE, RADIATOR 1-1/8 50 FT BULK
8	17-717	1	HOSE, LOWER ENGINE THERMAL
9	51-011	1	CASTING, Y COOLANT ADAPTOR
10	17-718	1	HOSE, LOWER ENGINE TO HELICOIL
11	17-719	1	HOSE, LOWER ENGINE TO RADIATOR
12	14-010	6	CLAMP, HOSE #32
13	16-029	42"	HOSE, FUEL 3/8 IN 30R7
14	36-140	1	BOTTLE, O FLOW 2 LITER
15	16-029	22"	HOSE, FUEL 3/8 IN 30R7
16	36-115	1	HOSE, UPPER RADIATOR THERMAL
17	63-000	1	RADIATOR, RS-4849 NISSAN A-15
18	14-007	3	CLAMP, HOSE #4
19	40-002	1	CAP, RADIATOR A-15

SECTION 5




5-9

**AIR CLEANER**

Item No.	Part Number	Qty	Description
1	16-009	5	HOSE, INT VAC 2 IN.
2	36-086	1	ELBOW, 2-1/4 X 45 DEG DONALD
3	64-001	1	TBG, SS 1-1/4 X 3 INCH AIR CLEANER
4	36-085	1	ELBOW, 2-1/4 X 90 DEG DONALD
5	36-082	1	ASSY, AIR CLEAN CAN. DONALDSON
6	36-084	1	CAP, RAIN AIR CLN. DONALDSON
7	36-128	1	ELEMENT, AIR DONALDSON THERMAL
8	36-083	2	BAND, MTG. AIR CLN. DONALDSON
9	11-005	3	NUT, 5/16-18 ZINC
10	12-016	3	LKWSR, 5/16 ZINC
11	12-012	6	WASHER, FLAT 1/4 SAE
12	66-056	3	STANDOFF, THERMAL AIR CLNR
13	10-037	3	SCREW, MACH 5/16-18 X 2 HXHD

SECTION 5




5-10

**WATER TRANSFER SYSTEM**

Item No.	Part Number	Qty	Description
1	25-005	1	DSC, 3/8X3/8FP BR
2	21-073	1	COUPLING, 3/8 STD BRASS
3	21-035	1	CONN, 3/8 M X 1/2 FP
4	21-032	1	FTTG, BARB 1/2 P X 3/4 H BRASS
5	17-059	1	HOSE, WATER 3/4 X 54 IN
6	69-007	1	ASSY, WATER BOX THERMAL
7	17-057	1	HOSE, WATER 3/4 X 30 IN
8	69-014	1	ASSY, WTR PUMP THERMAL
9	23-030	1	VLV, BYPASS 1/2 IN 180 DEG BRASS
10	18-035	1	HOSE, 1/2 X 18 1/2 FT X 1/2 FT W/CVR
11	69-016	1	ASSY, HELI COIL
12	18-033	1	HOSE, 1/2 X 10 1/2 FT X 1/2 FT W/CVR
13	69-006	1	ASSY, PRESS REG THERMAL
14	18-034	1	HOSE, 1/2 X 11 1/2 FT X 1/2 FT W/CVR
15	46-020	1	ACCUMULATOR, CAT 6026
16	18-037	1	HOSE, 1/4 X 44 1/2 FT X 1/2 FT W/CVR
17	69-008	1	ASSY, H.E. THERMAL
18	18-036	1	HOSE, 1/2 X 27 1/2 FT X 1/2 FT W/CVR
19	69-012	1	ASSY, THERMOSTAT MNFLD
20	18-031	2	HOSE, 3/16 X 24-3/4 1/4 FT X 1/4 FT
21	69-011	1	ASSY, WTR. BYPASS MNFLD
22	18-097	1	HOSE, 3/16 X 55 1/4FT X 1/4FT
23	18-030	2	HOSE, 3/16 X 14-3/4 1/4 FT X 1/4 FT
24	18-029	1	HOSE, 3/16 X 11-3/4 1/4 FT X 1/4 FT
25	17-058	1	HOSE, WATER 3/4 X 40 IN.
26	26-005	1	GAUGE, WTR. PRESS1500PSIDUAL
27	69-010	1	69-010 ASSY, SOLUTION OUTLET THERMAL
28	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP
29	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP

SECTION 5




5-11

**69-007 WATER BOX THERMAL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	51-002	1	MOLDING, WATER BOX DISCOVERY
2	21-025	1	CAP, 5 IN. WATER BOX/TANK BLACK
3	23-025	1	VLV, FLOAT WTR BOX THERMALWAVE
4	11-001	2	NUT, SS 1/4-20
5	64-000	1	ROD, FLOAT SS THERMAL WAVE
6	28-001	1	BALL, FLOAT
7	21-072	1	NIP, HEX 3/4 MP 1/2 MP
8	20-001	1	STRAINER, SUCTION END 3/4FP
9	21-034	1	ELL, STREET 1/2 BRASS
10	21-032	3	FTTG, BARB 1/2 P X 3/4 H BRASS
11	21-044	1	ELL, STREET 1/2 IN. 45 DEG BRASS
12	66-089	1	ELL, 1/2 STREET W/ 1/8 PORT
13	21-054	1	ELL, 1-8 P X 1-4 T BRASS
14	23-011	1	VLV, TEMP REL 180DEG
15	21-001	1	CONN, 1/8 P X 1/4 T BR
16	18-097	1	HOSE, 3/16 X 55 1/4FT X 1/4FT
17	14-000	3	CLAMP, HOSE #12
18	17-057	1	HOSE, WATER 3/4 X 30 IN
19	17-058	1	HOSE, WATER 3/4 X 40 IN
20	17-059	1	HOSE, WATER 3/4 X 54 IN
21	18-031	1	HOSE, 3/16 X 24-3/4 1/4 FT X 1/4 FT

SECTION 5




5-12

**69-014 WATER PUMP (THERMAL) ASSEMBLY**

Item No.	Part Number	Qty	Description
1	46-017	1	PUMP, CAT 340 HT REVERSE SHAFT
2	35-003	1	CLUTCH, ELECT CAT 340 20MM
3	21-032	1	FTTG, BARB 1/2 P X 3/4 H BRASS
4	21-065	1	PLUG, 1/2 SOLID BRASS HEXHD
5	21-062	2	TEE, 3/8 F X M X F BRASS
6	21-057	2	CONN, 3/8 P X 1/2 T BRASS
7	21-061	1	ELL, 3/8 P X 1/2 T BRASS Elbow
8	61-016	1	MT. PUMP CAT 340 HT
9	61-028	2	PLT, BOLT CAT PUMP
10	11-006	4	NUT, 3/8-16 ZINC
11	12-014	4	LKWSR, 3/8 ZINC
12	12-013	5	WASHER, FLAT 3/8 SAE
13	10-008	4	SCREW, MACH 8MM-16 X 1.25MM
14	10-030	1	SCREW, MACH 3/8-16 X 3 HXHD
15	66-068	2	ADAPTOR, WATER PUMP
16	21-050	1	CONN, 1/4 P X 1/4 T BRASS
17	21-047	1	NIP, 1/2 IN. HEX BRASS
18	23-030	1	VLV, BYPASS 1/2 IN 180 DEG BRASS
19	21-034	1	ELL, STREET 1/2 BRASS
20	21-101	2	FTTG, BARB 1/2 P X 3/8 B BRASS
21	29-005	1	SWITCH, PRESS (1000PSI)
22	29-004	1	SWITCH, PRESS (50PSI)
23	46-012	1	PUMP, CHEMICAL STAINLESS STEEL
24	14-000	1	CLAMP, HOSE #12
25	17-057	1	HOSE, WATER 3/4 X 30 IN
26	18-034	1	18-034 HOSE, 1/2 X 11 1/2 FT X 1/2 FT W/CVR
27	18-054	1	HOSE, 1/2 X 15 1/2 FT X 1/2 FT
28	18-035	1	HOSE, 1/2 X 18 1/2 FT X 1/2 FT W/CVR
29	18-047	1	HOSE, 3/16 X 5 1/4 FT X 1/4 FT
30	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP
31	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP
32	21-096	1	PLUG, 1/4 IN T BRASS


SECTION 5



**69-016 HELI-COIL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	61-021	1	CASING, HELI-COIL
2	23-008	1	COCK, DRN 1-4 PX1-4HOS ELL BR
3	63-008	1	COIL, HELI COIL ASSY
4	41-012	1	GASKET, FLANGE HELI COIL
5	41-011	2	GASKET, MNFLD HELI COIL
6	61-022	1	LID, HELI-COIL
7	14-003	2	CLAMP, WIRE 1 IN X 3/8
8	58-013	2	RING, LOCK HELI COIL
9	66-016	2	NUT, 1-3/4-12 HEXHEAD HELIX COIL
10	10-038	10	SCREW, MACH 1/2-13 X 1 HXHD
11	11-011	12	NUT, 1/2-13 ZINC
12	12-018	24	WASHER, FLAT 1/2 SAE
13	12-019	12	LKWSR, 1/2 ZINC
14	10-002	2	SCREW, MACH 1/2-13 X 1-1/4 HEXHD
15	21-074	2	3/4 M NPT x 1/2 JIC
16	21-078	2	ELL, STREET PIPE 3/4 DEG
17	66-033	2	3/4 NPT TO 1-1/8 HOSE
18	14-006	2	CLAMP, HOSE #20
19	17-718	1	HOSE, LOWER ENGINE TO HELICOIL
20	36-115	1	HOSE, UPPER RADIATOR THERMAL
21	10-039	4	SCREW, MACH 7/16-14 X 1-1/2 HXHD
22	12-021	6	WASHER, FLAT 7/16 ZINC
23	12-020	4	LKWSR, 7/16 ZINC
24	11-012	4	NUT, 7/16-14 ZINC

SECTION 5




5-14

**69-006 PRESS REG THERMAL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	23-021	1	REG, PRESS CAT #7670 VITON
2	21-017	2	CONN, 3/8 P X 1/4 T BR
3	21-062	2	TEE, 3/8 F X M X F BRASS
4	21-061	1	ELL, 3/8 P X 1/2 T BRASS
5	21-046	1	NIP, 3/8 IN. HEX BRASS
6	21-080	1	FTTG, BULHEAD 3/8 BRASS
7	21-040	1	ELL, STREET 3/8 IN. BRASS
8	21-081	1	FTTG, BARB 3/8 X 3/8 HOSE
9	21-035	1	CONN, 3/8 M X 1/2 FP
10	21-032	3	FTTG, BARB 1/2 P X 3/4 H BRASS
11	14-000	3	CLAMP, HOSE #12
12	18-030	1	HOSE, 3/16 X 14-3/4 1/4 FT X 1/4 FT
13	16-004	5	HOSE, WTR. 3/4 IN HRZ. 500 FT BULK
14	18-033	1	HOSE, 1/2 X 10 1/2 FT X 1/2 FT W/CVR
15	18-029	1	HOSE, 3/16 X 11-3/4 1/4 FT X 1/4 FT
16	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP
17	21-111	1	TEE, STREET 1/2M X 1/2M X 1/2 F
18	21-101	1	FTTG, BARB 1/2 P X 3/8 B BRASS
19	16-033	16"	HOSE, 3/8 IN 300 PSI INSTA GRIP
20	14-011	2	CLAMP, HOSE FUEL # 6
21	21-146	1	PLUG, 3/8 NPT BRASS

SECTION 5




5-15

**69-070 ASSY, CAT ACCUMULATOR**

Item No.	Part Number	Qty	Description
1	46-020	1	ACCUMULATOR, CAT 6026
2	66-045	1	COUPLING, DBL END 1-1/8 IN BRASS
3	21-015	1	ELL, 1/2 PX 1/2T BR
4	18-034	1	HOSE, 1/2 x 11-1/2 FT x 1/2 FT W/CVR

SECTION 5




5-16

**69-008 H.E. THERMAL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	63-007	1	COIL & CASING H.E. THERMAL WAVE
2	41-000	1	GASKET, EXH FLG H.E.
3	51-003	1	CASTING, END, HEAT EXCHANGER
4	10-011	8	SCREW, MACH 1/4-20 x 1 SS
5	11-001	8	NUT, 1/4-20 SS
6	12-003	8	LKWSR, 1/4 SS
7	66-015	1	NUT, ADAPTOR BUSHING HE
8	66-013	1	FITTING, TEMP SENSOR ADAPTOR
9	34-008	1	SENSOR, TEMP 285 DEG NASON
10	21-015	1	ELL, 1/2 P x 1/2 T BR
11	10-026	2	SCREW, MACH 1/4-20 x 1 HXHD
12	12-012	2	WASHER, FLAT 1/4 SAE
13	12-015	2	LKWSR, 1/4 ZINC
14	11-004	2	NUT, 1/4-20 ZINC
15	11-006	2	NUT, 3/8-16 ZINC
16	12-013	4	WASHER, FLAT 3/8 SAE
17	10-029	2	SCREW, MACH 3/8-16 x 1 HXHD
18	18-037	1	HOSE, 1/4 x 44, 1/2 FT x 1/2 FT W/CVR
19	18-036	1	HOSE, 1/2 x 27, 1/2 FT x 1/2 FT W/CVR

SECTION 5




5-17

**69-012 THERMOSTAT MNFLD ASSEMBLY**

Item No.	Part Number	Qty	Description
1	66-010	1	MANIFOLD, THERMOSTAT
2	21-061	1	ELL, 3/8 P X 1/2 T BRASS
3	21-021	1	UNION, CAPILLARY-THERM 1/2 P
4	21-054	1	ELL, 1-8 P X 1-4 T BRASS
5	21-057	1	CONN, 3/8 P X 1/2 T BRASS
6	66-037	1	FTTG, TEMP SENSOR SUPPORT
7	34-000	1	SENDER, TEMP 140-320 DEGREE
8	21-048	1	PLUG, 1/8 IN. BRASS
9	18-031	1	HOSE, 3/16 X 24-3/4 1/4 FT X 1/4 FT
10	18-050	1	HOSE, 1/2 X 8-1/2 1/2FT X 1/2 FT W/CVR
11	18-036	1	HOSE, 1/2 X 27 1/2 FT X 1/2 FT W/CVR
12	34-007	1	CONTROL, TEMP 275 DEGREE
13	16-026	21"	HOSE, WINDSHIELD WIPER 50 FT BULK
14	10-028	2	SCREW, MACH 1/4-20 X 2-3/4 HXHD
15	12-012	4	WASHER, FLAT 1/4 SAE
16	12-015	2	LKWSR, 1/4 ZINC
17	11-004	2	NUT, 1/4-20 ZINC

SECTION 5




5-18

**69-010 SOLUTION OUTLET THERMAL ASSEMBLY**

Item No.	Part Number	Qty	Description
1	21-061	1	ELL, 3/8 P X 1/2 T BRASS
2	66-012	1	MANIFOLD, CHECK VALVE (YSTRAIN)
3	21-054	1	ELL, 1/8 P X 1/4 T BRASS
4	21-046	1	NIP, 3/8 IN. HEX BRASS
5	21-041	1	TEE, 3/8 IN. BRASS
6	21-040	2	ELL, STREET 3/8 IN. BRASS
7	21-052	2	NIP, 3/8 X 1/4 HEX BRASS
8	25-001	2	DSC, 1/4 X 1/4FP BR
9	23-023	1	VLV, CHECK, CHECK VLV MANIFOLD
10	20-018	1	SCREEN, CHECK VALVE MANIFOLD
11	41-007	1	ORING, 7/8 ID 1-1/16 OD
12	18-030	1	HOSE, 3/16 X 14-3/4 1/4FT X 1/4FT
13	18-034	1	HOSE, 1/2 X 11 1/2FT X 1/2FT W/CVR


SECTION 5



5-19

**69-011 WATER BYPASS MANIFOLD ASSEMBLY**

Item No.	Part Number	Qty	Description
1	66-011	1	MANIFOLD, BYPASS
2	21-056	1	NIP, HEX 1/4 X 1/8 BRASS
3	23-014	1	VLV, SOLEN 1/4FPX 1/4FP
4	21-064	1	ELL, 1/4 P X 1/4 T BRASS
5	20-015	1	SCREEN, BYPASS MNFLD
6	41-003	2	ORING, .676ID .816OD
7	66-019	1	ORIFICE, BYPASS MNFLD. RED
8	66-017	1	CAP, CHECK VLV. BYPASS MNFOLD.
9	21-054	2	ELL, 1-8 P X 1-4 T BRASS
10	18-030	1	HOSE, 3/16 X 14-3/4 1/4 FT X 1/4 FT
11	18-031	1	HOSE, 3/16 X 24-3/4 1/4 FT X 1/4 FT
12	18-097	1	HOSE, 3/16 X 55 1/4FT X 1/4FT




5-20B

### VACUUM CATALYTIC EXHAUST SYSTEM

Item No.	Part Number	Qty	Description
1	69-040	1	ASSY,VAC BRAKE 5M
2	69-015	1	ASSY, VACUUM PUMP THERMALWAVE®
3	63-001	1	MUFFLER, VACUUM 5M
4	16-017	60"	TUBING, IMPOLENE 250FT.
5	16-017	60"	TUBING, IMPOLENE 250FT.
6	21-028	1	CONN, 1/8 P X 1/4 POLY
7	28-000	1	CUP, OILFILL 1/8P
8	26-004	1	GUAGE, VAC 30in.HG DUALSCALE
9	69-042	1	ASSY, DVRT VALVE CATALYST TM5
10		1	EXHAUST ASSEMBLY

SECTION 5




5-21

**69-015 VACUUM PUMP ASSY**

Item No.	Part Number	Qty	Description
1	61-035	1	STEM, VACUUM RELIEF VLV 4L,5M
2	41-009	1	DIAPHRAGM, VAC RELIEF VLV 4L, 5M
3	66-001	1	VAC BRAKE, MACHINED 4L
4	58-106	1	SPACER, .125 X .688 X 1.625
5	58-108	1	SCREEN, SILENCER THERMAL
6	15-002	1	SPRING, VAC RELIEF VALVE
7	50-000	1	SILENCER, VAC BRAKE FOAM
8	58-077	1	WASHER,VAC SILENCER
9	11-012	2	NUT, 7/16-14 ZINC
10	21-011	2	ELL, 1/8 P X 1/4 POLY BR
11	16-017	60"	TUBING, IMPOLENE 250FT.
12	16-017	60"	TUBING, IMPOLENE 250FT.
13	61-034	1	ASSY, ADAPTOR VAC STANDPIPE
14	46-013	1	VACUUM PUMP 5M
15	14-004	1	CLAMP, WIRE 5/8 IN X 3/8
16	10-041	4	SCREW, MACH 7/16-14 X 1-1/4 HXHD
17	12-020	4	LKWSR, 7/16 ZINC
18	12-021	4	WASHER, FLAT 7/16 ZINC
19	64-002	1	NIP, HALF BLOWER OUTLET
20	14-026	2	CLAMP,HOSE #80
21	17-706	1	HOSE, INT VACUUM 4-1/2 X 4 IN.

## SECTION 5




5-22

### IDLER PULLEY ASSEMBLY


Item No.	Part Number	Qty	Description
1	69-015	1	ASSY, VACCUUM PUMP THERMALWAVE
2	10-026	3	SCREW, MACH 1/4-20 X 1 HXHD
3	64-005	1	KEYSTOCK, 1/4 SQUARE X 2 IN
4	12-015	3	LKWSR, 1/4 ZINC
5	38-014	1	HUB, SDS102
6	38-013	1	PULLEY, 2B66
7	66-009	1	PULLEY, NISSAN A15
8	10-004	2	SCREW, MACH 3/8-16 X 1-1/4 HEXHD
9	12-013	2	WASHER, FLAT 3/8 SAE
10	10-050	1	SCREW, MACH 1/2-13 X 1-1/2
11	12-022	1	LKWSR, INT TOOTH 1/2 IN
12	10-051	1	SCREW, SET 5/16-18 X 1/2
13	12-014	2	LKWSR, 3/8 ZINC
14	61-152	1	ASSY, TENSIONER HOUSING W/HEX
15	38-025	1	ARM, BELT TENSIONER DISCOVERY
16	66-083	1	SHAFT, TENSIONER THERMAL
17	39-018	2	BEARING, 35MM X 72MM X 17MM
18	66-067	1	PULLEY, TENSIONER 4.40 2G
19	11-024	1	NUT, 5/8-11 NYLOK Z
20	15-009	2	BUMPER, TESIONER STOP
21	58-102	2	SPACER, .190 X .937OD X .375ID
22	58-103	2	SPACER, .190 X 1.25OD X .375ID
23	11-019	2	NUT, 3/8-16 NYLOK
24	37-041	2	BELT, 5VX550
25	SPACER(S)*	1	SPACER(S)* AS NEEDED

SECTION 5



**69-042 ASSY, DVRT VALVE CATALYST TM5**

Item No.	Part Number	Qty	Description
1	30-018	1	SOLENOID, RTV. DIV. VLV. DSCVRY
2	58-056	1	BRKT,ADJ. DIV SOLENOID
3	12-017	3	WASHER, FLAT 5/16 SAE
4	11-005	5	NUT, 5/16-18 ZINC
5	39-016	1	COUPLING, FLEX D-BORE
6	10-006	3	SCREW, MACH 1/4-20 X 1/2 HEXHD
7	12-003	3	LKWSR, 1/4 IN SS
8	51-006	1	CASTING, CVR. DIVERTER VALVE
9	66-036*	1	BUSHING, BRASS DIVERTER VLV.
10	51-007	1	CASTING, ACTUATOR DIVERTER VALVE
11	61-116	1	ASSY, DIVERTER THERMAL CATALYTIC
12	36-016	1	GASKET, EXHAUST ONAN #154-2747
13	61-117	1	ASSY, CATALYTIC EXHAUST THERMAL
14	43-002	1	WRAP, MUFFLER HI-TEMP
15	36-143	1	GASKET, NISSAN EXHAUST
16	58-087	1	BRKT, CATALYST MOUNT TM
17	14-027	2	CLAMP, MUFFLER 1-1/2 IN.
18	12-016	2	LKWSR, 5/16 ZINC
19	11-006	1	NUT, 3/8-16 ZINC
20	12-014	1	LKWSR, 3/8 ZINC
21	12-013	2	WASHER, FLAT 3/8 SAE
22	41-010	1	DIAPHRAGM, VAC RELIEF VLV 3L, 4M
23	10-056	1	BOLT,TAP 3/8-16 X 2 1/2 GR 5
24	14-001	1	CLAMP, MUFFLER 1-1/4 IN.




5-24

**MUFFLER-EXHAUST ASSEMBLY**

Item No.	Part Number	Qty	Description
1	63-001	1	MUFFLER, VACUUM 5M
2	14-002	2	CLAMP, MUFFLER 3 IN
3	63-010	1	ASSY, TUBE EXHAUST VAC MUFFLER 5M
4	63-014	1	MUFFLER, EXHAUST THERMAL WAVE
5	14-001	3	CLAMP, MUFFLER 1-1/4 IN
6	63-017	1	TUBE, EXHAUST 45 DEG THERMAL
7	63-004	1	TUBE, HE END

## SECTION 5




5-25

### CHEMICAL PUMPING SYSTEM

Item No.	Part Number	Qty	Description
1	20-002	1	STRAINER, SUCTION END 1/8FP
2	21-007	1	FTTG, BRB 1/8P x 5/16H BR
3	17-301	2	HOSE, BRAIDED 5/16 x 77 IN
4	26-003	1	FLOWMETER, 1/8FP
5	17-303	1	HOSE, CHEM TO FLWMTR 3/8 x 21 IN
6	46-012	1	PUMP, CHEMICAL STAINLESS STEEL
7	18-031	1	HOSE, 3/16 x 24-3/4 1/4FT x 1/4FT
8	23-027	1	VLV, 3-WAY BALL 1/8 FP SS
9	18-029	1	HOSE, 3/16 x 11-3/4 1/4FT x 1/4FT
10	23-028	1	VLV, MET 1/8FP (CHEM) RT ANG SS
11	18-016	1	HOSE, 3/16 x 16-1/2 1/4FT x 1/4FT
12	69-010	1	ASSY, SOLUTION OUTLET THERMAL
13	69-014	1	ASSY, WTR PUMP THERMAL
14	10-007	4	SCREW, MACH 1/4-20 x 1/2 SOCHD SS
15	12-002	4	WASHER, FLAT 1/4 SS ANC
16	12-003	4	LKWSR, 1/4 IN SS


SECTION 5



5-26

**46-012 CHEMICAL PUMP, STAINLESS STEEL**

Item No.	Part Number	Qty	Description
1	66-008	1	BODY, CHEMICAL PUMP STAINLESS
2	36-004	2	VLV, CHECK HYPRO
3	41-007	2	O-RING, 7/8 ID, 1-1/16 OD
4	66-006	2	CAP, CHECK VALVE CHEM PUMP SS
5	36-003	1	DISC, CHEM PUMP
6	36-000	1	DIAPHRAGM, CHEM PUMP
7	66-007	1	COVER, CHEM PUMP STAINLESS
8	66-002	1	ADAPTOR, CHEMICAL PUMP
9	21-038	1	ELL, STREET 1/8 IN BRASS
10	21-007	1	FTTG, BRB 1/8P x 5/16H BR
11	14-011	1	CLAMP, HOSE FUEL #6
12	21-066	1	ELL, 1/8P x 1/4T SS
13	17-303	1	HOSE, CHEM TO FLWMTR 3/8 x 21 IN
14	18-031	1	HOSE, 3/16 x 24-3/4, 1/4 FT x 1/4 FT



44-000 DECAL SHEET, WARNING & CONTROLS




44-001 DECAL, HOOD BLUELINE




44-002 DECAL, THERMAL WAVE

ELECTRICAL DIAGRAM



SECTION 5




5-29

**68-009 ASSY, PRE-FILTER BOX WASTE TANK BOX TRUCK**

Item No.	Part Number	Qty	Description
1	61-012	1	ASSY, PRE-FILTER BOX
2	40-003	2	LATCH, PRE-FILTER BOX
3	61-002	1	BASKET, STRAINER WASTE TANK
4	61-020	1	ASSY, LID PRE-FILTER BOX
5	18-003	1	HOSE, VAC 2 IN. FLEX SUPER TM
6	19-009	1	CAP, WASTE TANK INLET
7	14-010	2	CLAMP, HOSE #32
8	17-421	1	HOSE, INT. VACUUM 2 IN X 6 FT
9	21-094	1	FTTG, 1-1/2 P X 2 H DRAIN
10	23-022	1	VLV, BALL 1-1/2 FP PVC DUMP

SECTION 5




5-30

**68-020 ASSY, PRE-FILTER BOX WASTE TANK V2**

Item No.	Part Number	Qty	Description
1	61-012V2	1	ASSY, PRE-FILTER BOX V2
2	40-003	2	LATCH, PRE-FILTER BOX
3	61-039	1	ASSY, STRAINER BSKT PRE-FLTR BOX V2
4	61-020V2	1	ASSY, LID PRE-FILTER BOX V2
5	18-003	1	HOSE, VAC 2 IN. FLEX SUPER TM
6	19-009	1	CAP, WASTE TANK INLET
7	14-010	2	CLAMP, HOSE #32
8	17-421	1	HOSE, INT. VACUUM 2 IN X 6 FT
9	21-094	1	FTTG, 1-1/2 P X 2 H DRAIN
10	23-022	1	VLV, BALL 1-1/2 FP PVC DUMP


**SECTION 5**



5-31

**67-001 WAND, LOW PROFILE 2 IN.**


Item No.	Part Number	Qty	Description
1	67-001	1	WAND, LOW PROFILE 2 IN
2	25-000	1	DSC, 1/4M X 1/4FP BR
3	27-013	1	VLV, WAND CMP
4	21-050	1	CONN, 1/4 P X 1/4 T BRASS
5	18-021	1	HOSE, 3/16 X 51 1/4FT X 1/4FT
6	24-000	4	TIP, SPRAY 95015X1/8P SST



**67-003 WAND, ERGONOMIC W-SPRAYER**

Item No.	Part Number	Qty	Description
1	67-003	1	WAND, ERGONOMIC W /SPRAYER
2	25-000	1	DSC, 1/4M X 1/4FP BR
3	23-035	1	VLV, SPRAYER HYPRO 3381-0032
4	21-050	1	CONN, 1/4 P X 1/4 T BRASS
5	18-021	1	HOSE, 3/16 X 51 1/4FT X 1/4FT
6	24-000	4	TIP, SPRAY 95015X1/8P SST
7	40-009	1	HANDLE, ERGO WAND COATED

SECTION 5




5-32

**68-021 ASSY, WST TNK REAR MOUNT V2**

Item No.	Part Number	Qty	Description
1	61-023V2	1	TANK, WASTE REAR THERMAL V2
2	40-003	2	LATCH, PRE-FILTER BOX
3	20-004	2	STRAINER, WST TNK 2 IN. 100 MESH
4	61-037	1	ASSY, LID WST TNK REAR MT
5	61-024	1	PANEL, INLET ACCESS WASTE TANK
6	41-018	4	GASKET, SPONGE 1 IN X 45 FT
7	61-027	1	ELBOW, WASTE TANK INLET
8	10-031	6	SCREW, THUMB 5/16-18 X 3/4
9	14-008	4	#072 Hose Clamp (76/127mm)
10	69-000	1	WIRING , LEVEL SENSOR SHUTOFF
11	21-051	1	ELL, 1/4 P X 1/4 T 45 DEG BRASS
12	19-009	2	CAP, WASTE TANK INLET
13	21-097	3	PLUG, 1-1/4 IN PVC
14	16-014	72	HOSE, INT VAC 3-1/2 IN 50 FT BULK


SECTION 5



5-33

**68-012 ASSY, WASTE TANK BOX TRUCK THERM**

Item No.	Part Number	Qty	Description
1	61-030	1	TANK, WASTE 150 GALLON BOX
2	61-029	1	HSG, FLTR WST TNK BOX TRUCK
3	41-018	8	GASKET, SPONGE 1 IN X 45 FT
4	61-024	1	PANEL, INLET ACCESS WASTE TANK
5	61-027	1	ELBOW, WASTE TANK INLET
6	14-008	4	CLAMP, HOSE #72
7	21-097	2	PLUG, 1-1/4 IN PVC
8	21-064	1	ELL, 1/4 P X 1/4 T BRASS
9	69-000	1	WIRING , LEVEL SENSOR SHUTOFF
10	20-004	2	STRAINER, WST TNK 2 IN. 100 MESH
11	10-031	9	SCREW, THUMB 5/16-18 X 3/4
12	16-014	72"	HOSE, INT VAC 3-1/2 IN 50 FT BULK


**10. ACCESSORIES**

5-34

**68-003 KIT, WASTE PUMP EXTERNAL**

Item No.	Part Number	Qty	Description
1	46-016	1	PUMP, DIAPHRAGM, PUMP OUT
2	45-008	1	MOTOR, GEAR BISON PUMPOUT
3	12-017	4	WASHER, FLAT 5/16 SAE
4	12-016	2	LKWSR, 5/16 ZINC
5	10-040	2	SCREW, MACH 5/16-18 X 3-1/2 SOCHD
6	11-005	2	NUT, 5/16-18 ZINC
7	61-003	1	MOUNT, EXTERNAL PUMPOUT
8	66-022	1	ADAPTOR, HOSE WASTE PUMP
9	66-023	1	NUT, ADPTR. HOSE WASTE PUMP
10	21-071	1	CAP, GARDEN HOSE 3/4 BRASS
11	58-006	1	BRKT, HOSE CONN WASTE PUMP
12	14-006	4	CLAMP, HOSE #20
13	16-004	72"	HOSE, WTR. 3/4 IN HRZ. 500FT BULK
14	69-000	1	WIRING, LEVEL SENSOR SHUTOFF
15	16-018	24"	HOSE, WTR. 1 IN HRZ. 100FT BULK
16	21-036	1	FTTG, BRB 1-1/4 P X 1 IN. BARB


# 1992 TO 2002 FORD FUEL LINE INSTALLATION



## 69-005FI KIT, FUEL HOOKUP FORD FI

Item No.	Part Number	Qty	Description
1	66-031	1	ADAPTOR, FUEL FILLER NECK FORD
2	14-000	2	CLAMP, HOSE #12
3	18-028	1	HOSE, 3/16 X 25 1/8P X 1/8P NO CVR
4	21-086	2	FTTG, BULKHEAD 1/4 IN. BRASS
5	21-006	4	FTTG, BRB 1/4PX5//16H BR
6	21-039	2	ELL, 1/4 IN LG STREET BRASS
7	14-011	6	CLAMP, HOSE FUEL #6
8	21-038	1	ELL, STREET 1/8 IN. BRASS
9	21-007	2	FTTG, BRB 1/8 P X 5/16 H BR


# 1997 OT 2002 CHEVY AND GMC FULL SIZE VAN FUEL LINE INSTALLATION



## 69-003FI KIT, FUEL HOOKUP 1997 TO 2002 FI

Item No.	Part Number	Qty	Description
1	14-010	2	CLAMP, HOSE #32
2	66-030	1	ADAPTOR, FUEL FILLER NECK CHEVY
3	21-116	1	ELL, 1/8FP 90 DEG BRONZE
4	14-011	6	CLAMP, HOSE FUEL #6
5	21-007	2	FTTG, BRB 1/8 PX 5/16 H BR
6	18-027	2	HOSE, 3/16 X 5 1/8P X 1/8P NO CVR
7	21-006	4	FTTG, BRB 1/4P X 5/16 H BR
8	21-039	2	ELL, 1/4 IN LG STREET BRASS
9	21-038	1	ELL, STREET 1/8 IN. BRASS
10	21-086	2	FTTG, BULKHEAD 1/4 IN. BRASS


## 2003 CHEVY AND GMC FULL SIZE VAN FUEL LINE INSTALLATION



### 69-018FI KIT, FUEL HOOKUP 2003 CHEVY FI

Item No.	Part Number	Qty	Description
1	66-034	1	ADAPTOR, FUEL FLR CHVY 2003
2	14-006	2	CLAMP, HOSE #20
3	18-028	1	HOSE, 3/16 X 25 1/8P X 1/8P NO CVR
4	14-011	6	CLAMP, HOSE FUEL #6
5	21-038	1	ELL, STREET 1/8 IN. BRASS
6	21-007	2	FTTG, BRB 1/8 PX 5/16 H BR
7	21-039	2	ELL, 1/4 IN LG STREET BRASS
8	21-006	4	FTTG, BRB 1/4PX5//16H BR
9	21-086	2	FTTG, BULKHEAD 1/4 IN. BRASS


# 1997 TO 2002 DODGE FULL SIZE VAN FUEL LINE INSTALLATION




5-38

## 69-004FI KIT, FUEL HOOKUP CHEVY/DODGE FI


Item No.	Part Number	Qty	Description
1	14-010	2	#32 Hose Clamp (40/63mm)
2	66-030	1	ADAPTOR, FUEL FILLER NECK
3	21-038	1	ELL, STREET 1/8 IN. BRASS
4	14-011	6	CLAMP, HOSE FUEL #6
5	21-007	2	FTTG, BRB 1/8 PX 5/16 H BR
6	18-028	1	HOSE, 3/16 X 25 1/8P X 1/8P NO CVR
7	21-086	2	FTTG, BULKHEAD 1/4 IN. BRASS
8	21-006	4	1/4 M NPT x 5/16 Hose Barb
9	21-039	2	ELL, 1/4 IN LG STREET BRASS




**69-032 KIT, 2004 TF ADAPTOR CHEVY**




**69-032 KIT, 2004 TF ADAPTOR CHEVY**



**69-041 ADAPTOR, 2003 FORD FUEL**




**69-047 ADAPTOR, 2003 FUEL INJ. FORD**




5-39

**68-002 KIT, DEMAND PUMP W/PLUMBING SS**




5-40

**68-013 ASSY, VAN STORAGE UNIT SS**




5-41

**68-014 ASSY, SINGLE 5 GAL JUG HOLDER**




5-42

**68-015 ASSY, FURN BLOCK HOLDER SS**



5-43


**68-016 RACK, DOUBLE CHEMICAL**




5-44

**68-017 ASSY, FIN 120 GAL WTR TNK**


**SECTION 5**



5-45  
**68-018 ASSY, 10 GAL CHEM RACK S.S.**




5-46  
**68-019 SPRAY BOTTLE HOLDER SS**




5-47

**68-022 ASSY, DBL PMP UP SPRAY RK, SS**




5-48

**68-024 ASSY, SNG PMP UP SPRAY RK, SS**




5-49

**68-023 ASSY, REEL HP SOLUTION**




5-50

**68-025 ASSY, HOSE REEL HIGH PROFILE**




**68-032 ASSY, H-REEL MOTORIZED W-H2O TNK**




**68-033 ASSY, HOSE REEL H. PROFILE W-MTR**


**SECTION 5**



**68-037 ASSY, HOSE REEL VAC ONLY**



**68-043 ASSY, HOSE REEL LAY DOWN KIT**



**68-045 ASSY, WATER SOFTENER**